

The NAVIC logo consists of a red square icon followed by the word "NAVIC" in a bold, black, sans-serif font.

NAVIC

CX0540 Rev 01.3

Automated Steerable Scanner

SAFETY WARNINGS / PRECAUTIONS

KEEP THIS MANUAL – DO NOT LOSE

THIS MANUAL IS PART OF THE **NAVIC** SYSTEM AND MUST BE RETAINED FOR THE LIFE OF THE PRODUCT. PASS ON TO SUBSEQUENT OWNERS.

Ensure any amendments are incorporated with this document.



WARNING! The **NAVIC** is designed for a specific use. Using the **NAVIC** outside of its intended use is dangerous. Failure to comply with the warnings, instructions, and specifications in this manual could result in **SEVERE INJURY** or **DEATH**. Read and understand this manual before using.



WARNING! FALLING OBJECT HAZARD. The area below a crawler must be kept clear at all times. A clearly marked **NO ENTRY ZONE** must be cordoned off directly below the area of crawler operation.

(see “Preparation for Safe Use” on page 38 for additional details)

WARNING! Do **NOT** operate or place crawler on a surface higher than 2 m (6 ft) without a proper tether held taut at all times.

(see “Tether Requirements and Attachment” on page 39 for additional details)



WARNING! ELECTRICAL CORDS CAN BE HAZARDOUS. Misuse can result in **FIRE** or **DEATH** by **ELECTRICAL SHOCK**. Inspect thoroughly before each use. Do **NOT** use if damaged. Do **NOT** use when wet. Keep away from water. Do **NOT** drive, drag or place objects over cord.



WARNING! Do **NOT** operate scanner in an explosive environment. Do **NOT** operate scanner in the presence of volatile substances.



WARNING! MAGNETIC MATERIAL. The wheels of the crawler produce an extremely strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics.



Tools, magnets and metal objects can cut, pinch or entrap hands and fingers. **HANDLE WITH CARE.**

People with pacemakers or ICD's must stay at least 75 cm (30 in) away.

WARNING! MAGNETIC MATERIAL. The handheld controller produces a strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics.

People with pacemakers or ICD's must stay at least 10 cm (4 in) away.

WARNING! MAGNETIC MATERIAL. When the carrying case contains the crawler, a magnetic field exists outside the case which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics.

People with pacemakers or ICD's must stay at least 10 cm (4 in) away from the carrying case when it contains the crawler.

WARNING! MAGNETIC MATERIAL. The installation/removal mat (see "Scanner Installation/Removal Mat Use" on page 130) contains magnetic material.

People with pacemakers or ICD's must stay at least 10 cm (4 in) away.



WARNING! LASER RADIATION. The battery powered optical guide contains a Class 1M laser. Do not view directly with optical instruments.



WARNING! If this product is to be used with any Child Products listed in (Chaper 2.3), be sure to read and comply with the warnings, instructions, and specifications in the Child Product's User Manual(s).



WARNING! DO NOT DISASSEMBLE. No user-serviceable parts. Disassembling any of the components in this product, beyond the instructions in this user manual, could void the regulatory certifications and/or effect the safety of the product.



CAUTION! Pinch points exist with this product. Keep fingers and hands clear of pinch points.



CAUTION! Do **NOT** operate the **NAVIC** crawler on an inspection surface which is electrically connected to a component that is being welded.



CAUTION! **DO NOT DISCONNECT UNDER LOAD.** Shut off power before connecting or disconnecting. Permanent damage to electronics could occur.



STOP. This symbol indicates stop button.



The **WEEE** symbol indicates that the product must not be disposed of as unsorted municipal waste, but should be collected separately.

(see “Disposal” on page 180 for additional details)

TABLE OF CONTENTS

1

Identification	1
1.1. Product Brand	1
1.2. Manufacturer	1
1.3. Compliance Declarations	1
1.3.1. ISED Emissions Compliance (Canada).....	1
1.3.2. FCC Suppliers Declaration of Conformity (United States).....	1
1.3.3. European Union CE Declarations	2
1.3.4. UKCA Declarations	2

2

Product Specifications	3
2.1. Base NAVIC System.....	3
2.1.1. Intended Use	3
2.1.1.1. Operating Limits	4
2.1.1.2. Operating Environment.....	5
2.1.1.3. User.....	5
2.1.2. Unintended Use.....	5
2.1.3. Dimensions and Weight	6
2.1.4. Power Requirements.....	8
2.1.5. Environmental Sealing	8
2.1.6. Performance Specifications	8
2.1.7. Encoder Interface Specifications	9
2.2. Compatible Components	10
2.2.1. Low Profile Probe Holder Frame	10
2.2.1.1. Intended Use	10
2.2.1.2. Operating Limits	10
2.2.2. Vertical Probe Holder Frame	10
2.2.2.1. Intended Use	10
2.2.2.2. Operating Limits	10
2.2.3. Pivoting Probe Holder Frame	11
2.2.3.1. Intended Use	11

2.2.3.2	Operating Limits	11
2.2.4.	Frame Bar	11
2.2.4.1	Intended Use	11
2.2.4.2	Operating Limits	11
2.2.5.	Preamp Bracket	12
2.2.5.1	Intended Use	12
2.2.5.2	Operating Limits	12
2.2.6.	NAVIC Backpack	12
2.2.6.1	Intended Use	12
2.2.6.2	Operating Limits	12
2.2.7.	NAVIC Camera Mount	13
2.2.7.1	Intended Use	13
2.2.7.2	Operating Limits	13
2.2.8.	Battery Powered Optical Guide	13
2.2.8.1	Intended Use	13
2.2.8.2	Operating Environment	13
2.2.8.3	Power Requirements	13
2.2.8.4	Environmental Sealing	13
2.2.9.	Medium Temperature Add-On Kit	14
2.2.9.1	Intended Use	14
2.2.9.2	Operating Limits	14
2.3.	Child Products	15
2.3.1.	Motorized Couplant Pump	15
2.3.2.	Motorized Raster Arm	15
2.3.3.	Corrosion Actuated Probe Lift	15
2.3.4.	Preamp	15
2.3.5.	Optical Guide	16
2.3.6.	Tracker	16
2.3.7.	Battery Kit	16

3	Definitions	17
3.1.	Definition of Symbols	17
3.2.	Definitions of Terms	17
3.3.	Safety Symbols	18
3.4.	Safety Signal Words	18

4	System Components	19
4.1.	Base System Components	19
4.1.1.	NAVIC Crawler	19
4.1.1.1	Right Drive Module	19
4.1.1.1	Encoder	20
4.1.1.2	Left Drive Module	20

4.1.2.	Power Controller	21
4.1.2.1	AC/DC Power Supply	22
4.1.3.	Umbilical	23
4.1.3.1	Umbilical Connections	24
4.1.3.2	Stop Button	25
4.1.3.3	Encoder Signal Isolation	25
4.1.4.	Handheld Controller	26
4.1.5.	Auxiliary Cable	27
4.1.6.	J300 Encoder Cable	27
4.1.7.	Installation/Removal Mat	28
4.1.8.	Lifting Sling	28
4.1.9.	Irrigation Kit	29
4.1.10.	Cable Management	29
4.1.11.	Cap: NAVIC Hinge Cover	29
4.1.12.	Plug	30
4.1.13.	Battery	30
4.1.14.	Charger and Power Adapter	30
4.1.15.	Tools	30
4.1.16.	Cases	30
4.2.	Compatible Components	31
4.2.1.	Low Profile Probe Holder Frame	31
4.2.2.	Vertical Probe Holder Frame	31
4.2.3.	Pivoting Probe Holder Frame	31
4.2.4.	Frame Bar	31
4.2.5.	Slip Joint Probe Holder	32
4.2.6.	Vertical Probe Holder	32
4.2.7.	Heavy Duty Vertical Probe Holder	32
4.2.8.	Corrosion Thickness Probe Holder	32
4.2.9.	HydroFORM Cart	33
4.2.10.	Preamp Bracket	33
4.2.11.	NAVIC Backpack	33
4.2.12.	NAVIC Camera Mount	33
4.2.13.	Battery Powered Optical Guide	34
4.2.14.	Automated Crawler Medium Temperature Add-On Kit	34
4.2.15.	Encoder Adapter	34
4.2.16.	3-Axis Nozzle Scanner Add-On Kit	34
4.3.	Child Products	35
4.3.1.	Motorized Couplant Pump	35
4.3.2.	Motorized Raster Arm	35
4.3.3.	Corrosion Actuated Probe Lift	35
4.3.4.	Preamp Kit	35
4.3.5.	Optical Guide	36
4.3.6.	Tracker	36

4.3.7.	Battery Kit	36
4.4.	Tools	37
4.4.1.	Included Tools	37
4.4.2.	Optional Tools	37

5

Preparation for Use38

5.1.	Preparation for Transportation.....	38
5.2.	Preparation for Safe Use	38
5.2.1.	No Entry Fall Zone.....	38
5.2.2.	Tether Requirements and Attachment	39
5.2.3.	Lifting Sling Setup	40
5.2.4.	Lifting Sling Low Profile Setup.....	42
5.3.	Preparation of Inspection Surface.....	42
5.4.	System Connectivity	43
5.5.	NAVIC Configurations	45
5.5.1.	Single Drive Module with Frame Bar	45
5.5.2.	Crawler with Corrosion Actuated Probe Lift	47
5.5.3.	Crawler with Multiple Probe Holders.....	49
5.5.3.1	Vertical Probe Holder Frame	49
5.5.3.2	Low Profile Probe Holder Frame	51
5.5.3.3	Pivoting Probe Holder Frame	53
5.5.3.4	Flange	55
5.5.4.	3-Axis Nozzle Scanning	57
5.6.	Right Drive Module	59
5.6.1.	Swivel Mount	59
5.6.2.	Umbilical	60
5.6.3.	Handle	62
5.6.4.	Dovetail Accessory Mount	63
5.7.	Left Drive Module.....	64
5.7.1.	Swivel Mount	64
5.7.2.	Umbilical Connection	65
5.7.3.	Handle	65
5.7.4.	Dovetail Accessory Mount	65
5.8.	Handheld Controller	66
5.8.1.	Magnetic Mounts	66
5.8.2.	Connecting/Disconnecting Left and Right Modules	67
5.8.3.	Probe Holders.....	69
5.8.4.	Vertical Probe Holder	69
5.8.4.1	Probe Holder Setup	69
5.8.4.2	Probe Holder Vertical Adjustment	70
5.8.4.3	Probe Holder Transverse Adjustment	71
5.8.4.4	Probe Holder Longitudinal Adjustment	72

5.8.4.5	Probe Holder Left/Right Conversion	73
5.8.5.	Slip Joint Probe Holder	75
5.8.5.1	Probe Holder Setup	75
5.8.5.2	Probe Holder Adjustment	77
5.8.5.3	Probe Holder Force Adjustment	78
5.8.5.4	Slip Joint Probe Holder Left/Right Conversion.....	80
5.8.6.	Heavy Duty Vertical Probe Holder	82
5.8.6.1	Probe Holder Setup	82
5.8.6.2	Probe Holder Vertical Adjustment.....	84
5.8.6.3	Probe Holder Left/Right Conversion	84
5.8.6.4	Probe Holder 90° Adjustment.....	86
5.9.	3-Axis Nozzle Scanning	87
5.9.1.	Scanner Preparation	87
5.9.2.	3-Axis Nozzle Operation	92
5.9.3.	Encoded Skew Vertical Probe Holder	96
5.9.4.	Probe Holder Setup	96
5.9.5.	Skew Encoder Cable	98
5.9.6.	Encoded Skew Vertical Probe Holder Adjustment	98
5.9.6.1	Latch Pin	99
5.9.7.	Skew Angle Adjustment	100
5.9.7.1	Ratchet Lever	101
5.9.8.	Pivot Buttons	101
5.9.9.	Cable Clips.....	102
5.10.	Slider PPS.....	103
5.10.1.	Slider PPS Encoder	105
5.11.	Probe Holder Frames	106
5.11.1.	Vertical Probe Holder Frame - Flat or Circumferential Only	106
5.11.2.	Low Profile Probe Holder Frame - Flat or Circumferential Only	110
5.11.3.	Pivoting Probe Holder Frame	114
5.11.3.1	Mounting a Pivoting Probe Holder Frame	115
5.11.3.2	Pivoting Probe Holder Frame Setup - Longitudinal Scanning	116
5.11.3.3	Pivoting Probe Holder Frame - Circumferential Scanning	117
5.11.3.4	Pivoting Probe Holder Frame - Flange Scanning	118
5.11.3.5	Optical Guide Pivot Mount	120
5.12.	Accessories	121
5.12.1.	Battery Powered Optical Guide	121
5.12.2.	Cable Management	122
5.12.2.1	Mounting Cable Management	122
5.12.2.2	Cable Management Setup	122
5.12.2.3	Clamp Setup	123
5.12.3.	NAVIC Backpack	124
5.12.4.	Preamp Bracket	125
5.12.4.1	Mounting Preamp Bracket	125

5.12.4.2	Attaching Preamp with Screws	125
5.12.4.3	Attaching Preamp with Velcro Straps	126

6

Operation 127

6.1.	System Startup	127
6.2.	Placement of Crawler on Inspection Surface	129
6.2.1.	Scanner Installation/Removal Mat Use	130
6.3.	Operation.....	132
6.3.1.	Handheld Controller Layout	132
6.3.1.1	Touchscreen	133
6.3.1.2	D-pad	133
6.3.1.3	Joysticks	133
6.3.2.	Mode Select Screen	134
6.3.3.	Jog Mode	134
6.3.4.	Latched Jog Mode	136
6.3.5.	1 Axis Scan Mode	137
6.3.5.1	1 Axis Scan Screen	138
6.3.6.	System Utilities Screen	140
6.3.6.1	User Settings Screen	141
6.3.6.2	Diagnostics Screens	142
6.3.6.2.1	Detected Modules	142
6.3.6.2.2	System 1	143
6.3.6.2.3	System 2	143
6.3.6.2.4	System 3	144
6.3.6.2.5	LeftDrv, Right Drv,	144
6.3.6.3	Touch Calibration Screen	145
6.3.6.4	Joystick Calibration Screen	146
6.3.6.5	Draw	147
6.3.7.	High Internal Temperature Screen	147

7

Maintenance..... 149

7.1.	Safety Precautions Before Maintenance	149
7.2.	Cleaning.....	149
7.3.	Maintenance Schedule	150

8

Troubleshooting 151

8.1.	Startup Issues	151
8.1.1.	Joystick Off Center	151
8.1.2.	Checking Network	151
8.2.	Startup Override	152
8.2.1.	Scan Devices	153
8.2.2.	Reset Parameters	154

8.2.3.	System Parameters	154
8.2.4.	Device Address	154
8.3.	Encoder Failure	155
8.4.	Umbilical Troubleshooting	156
8.5.	Additional Issues	156
8.6.	Retrieval of a Stranded Crawler	157
8.7.	Technical Support	157

9

Service and Repair158

10

Spare Parts159

10.1.	Crawler	159
10.2.	Kit Components	160
10.2.1.	Encoder Connector Type	162
10.2.2.	Power Cord Type	162
10.3.	Cable Management	163
10.3.1.	Cable Management Sleeving	163
10.4.	Probe Holder Frame	164
10.5.	Low Profile Probe Holder Frame	165
10.6.	Pivoting Probe Holder Frame	166
10.7.	Slip Joint Probe Holder Parts	167
10.8.	Vertical Probe Holder Parts	168
10.9.	Heavy Duty Vertical Probe Holder	169
10.10.	Corrosion Thickness Probe Holder	170
10.11.	Encoded Skew Vertical Probe Holder	171
10.12.	3-Axis Nozzle Scanner Add-On Kit	172
10.12.1.	Slider PPS Encoded Leadscrew	173
10.13.	Probe Holder Components	173
10.13.1.	Arm Style	173
10.13.2.	Yoke Style	173
10.13.3.	Swing Arm Style	173
10.13.4.	Heavy Duty Yoke Style	173
10.13.5.	Pivot Button Style	174
10.14.	Probe Holder Receptacle and Wear Plate	174
10.15.	Variable Components	175
10.15.1.	Frame Bar	175
10.15.2.	Automated Crawler Medium Temperature Add-On Kit	176
10.16.	Accessories	177
10.16.1.	Preamp Bracket	177

10.16.2.	NAVIC Backpack	177
10.16.3.	Battery Powered Optical Guide	178
10.17.	Cases.....	179

11	Disposal	180
----	----------------	-----

12	Limited Warranty	181
----	------------------------	-----

IDENTIFICATION

1.1. Product Brand

This user manual describes the proper safety precautions, setup and use of the **NAVIC** system.

1.2. Manufacturer

Distributor:

Manufacturer:

Jireh Industries Ltd.
53158 Range Road 224
Ardrossan, Alberta, Canada
T8E 2K
Phone: 780.922.4534
jireh.com

1.3. Compliance Declarations

1.3.1. ISED Emissions Compliance (Canada)

CAN ICES-003(A) / NMB-003(A)

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

1.3.2. FCC Suppliers Declaration of Conformity (United States)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

RESPONSIBLE PARTY NAME:	Jireh Industries
ADDRESS:	2955 S Sam Houston Pkwy E Suite 300 Houston, Texas United States 77047
TELEPHONE:	832-564-0626

1.3.3. European Union CE Declarations

Jireh Industries hereby declares that the **NAVIC** product complies with the essential requirements and other relevant provisions of the following European Union directives:



2014/30/EU	EMC Directive
2014/35/EU	Low Voltage Directive
2012/19/EU	Directive on Waste Electrical and Electronic Equipment
2011/65/EU	Directive on Restriction of Hazardous Substances (RoHS)

1.3.4. UKCA Declarations

Jireh Industries hereby declares that the **NAVIC** product complies with the essential requirements and other relevant provisions of the following UK directives.



Title	Edition/Date of Issue
Electromagnetic Compatibility Regulations	2016
Electrical Equipment (Safety) Regulations	2016
Waste Electrical and Electronic Equipment Regulations	2013
Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations	2012

PRODUCT SPECIFICATIONS

2.1. Base NAVIC System

This section outlines the product specifications of the base system. When the base system is used together with compatible components (*Chapter 2.2*) or child products (*Chapter 2.3*), the product specifications of the base system may be superseded. See (*see “Compatible Components” on page 10*) and (*see “Child Products” on page 15*).

2.1.1. Intended Use



WARNING! FALLING OBJECT HAZARD.

The **NAVIC** is intended for a specific use. Read and understand the intended and unintended use limits below. Using the **NAVIC** outside of its intended use is dangerous and could result in **SEVERE INJURY** or **DEATH**.

The **NAVIC**'s primary purpose is to perform inspections of ferrous assets such as pipes, vessels, or storage tanks by moving an inspection tool over a ferrous surface. It is intended for industrial use only.

2.1.1.1 Operating Limits

Category	Parameter	Specification
Inspection Surface	Maximum coating thickness:	
	Up-side-down orientation	Bare metal only
	Vertical orientation	0.5 mm (0.020 in)
	Horizontal, Right-side-up orientation	1 mm (0.040 in)
	Condition	Clean, free of excess rust, scale, debris (i.e. dirt, sand, etc.), ice, frost
	Minimum thickness	3 mm (0.120 in)
	Minimum ID, internal circumferential driving	610 mm (24 in)
	Minimum OD, external Circumferential driving	70 mm (2.75 in)
	Minimum OD, longitudinal driving	305 mm (12 in)
	Maximum surface temperature	50°C (122°F)

Category	Parameter	Specification
Scanner	Maximum umbilical length	30 m (100 ft)
	Maximum payload (performance may vary with surface condition)	10 kg (23 lb) (Umbilical and attachments are considered payload)
	Attachments	Restricted to those listed in compatible components or child products
	Orientation while driving at height >2 m (6 ft) on vertical surface	Umbilical strain relief to point downwards, or at worst, horizontal. It is not to point upwards
	Required radial clearance (handles removed, circumferential driving)	70 mm (2.75 in) on outer diameters <200 mm (8 in) 81.5 mm (3.2 in) on outer diameters >200 mm (8 in)

2.1.1.2 Operating Environment

The NAVIC is for use in dry industrial environments having ambient temperatures shown below. It is NOT intended for use in explosive environments.

Category	Parameter	Specification
Environment	Minimum ambient temperature	-20°C (-4°F)
	Maximum ambient temperature	50°C (122°F)*

* CAUTION! In some high temperature conditions, the surface temperatures may become too hot for prolonged touch. When operating with the maximum payload of 10 kg (23 lb) and at an ambient temperature of 50°C (122°F), reduce the operation to a 25% duty cycle with a maximum on time of 30 minutes to ensure safe surface temperatures. It is important that the operator be aware of the possibility of hot surfaces and utilize gloves when necessary.

The NAVIC has built-in temperature protections for its electronics and will warn the operator and shut down before temperatures are reached, which might damage the system (see “High Internal Temperature Screen” on page 147).

2.1.1.3 User

The NAVIC is intended to be used by persons who have read and understand the user manual. The intended user is to be a person without limitations in the physical abilities of the upper and lower limbs, sight, hearing, or anyone with a pacemaker.

For operating at a height greater than 2 m (6 ft), the NAVIC is intended to be used by two people:

1. a person who is trained in rigging and fall protection and is able to effectively apply the same safety principles to the crawler, and
2. a person who is trained to operate the NAVIC

2.1.2. Unintended Use

The NAVIC is NOT intended for:

- ▶ use outside of its intended use
- ▶ lifting/lowering objects or people (*i.e. using the Navic as a crane / elevator*)
- ▶ driving into / over obstructions, excluding standard weld caps
- ▶ installation on a surface on which welding is actively occurring

In addition to the above points, for operating at a height greater than 2 m (6 in), the crawler is NOT intended for:

- ▶ operation without a proper tether system

- ▶ operating up-side-down
- ▶ operating while oriented such that the umbilical strain relief points upward
(front for the Navic is lower than the umbilical connection).

2.1.3. Dimensions and Weight

Crawler height:	12.5 cm	4.9 in
Crawler width:	28.2 cm	11.1 in
Crawler depth:	30.8 cm	12.1 in
Crawler height (<i>handles removed</i>):	8.1 cm	3.2 in
Crawler width (<i>right drive module</i>):	16.1 cm	6.3 in
Crawler weight: *	7.7 kg	17 lb
Crawler weight (<i>right drive module</i>):	4.2 kg	9.3 lb




Fig. 1 - Crawler dimensions




Fig. 2 - Dual module dimensions






Fig. 3 - Single module dimensions

** Dual module configuration excluding case, attachments, umbilical, power controller and handheld controller.*


2.1.4. Power Requirements




WARNING! A reliable power source must be used to power the crawler. Connections must be secured to prevent accidental disconnection. Power failure may cause the crawler to freewheel down when operating in a vertical orientation. Portable generator usage is not recommended unless accompanied by the use of an uninterruptible power supply.



WARNING! Proper grounding of the power supply is important for safe operation. When a generator is used to supply power to the system (*not recommended*), the generator must be properly grounded (*refer to generator manual*).

CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.



CAUTION! Power must be supplied from an approved Jireh power source.

Input Voltage:	25-45VDC
Input Power:	320 W

2.1.5. Environmental Sealing

Dust-tight, watertight (*not submersible*).

2.1.6. Performance Specifications

Category	Parameter	Specification
Crawler	Maximum speed	25 cm/sec (10 in/sec)
	Encoder resolution, right module (<i>idler encoder</i>)	13.78 counts/mm (349.9 counts/in)
	Encoder resolution, left module (<i>motor encoder</i>)	872.5 counts/mm (22161.8 counts/in)

2.1.7. Encoder Interface Specifications

Output type: 4 channel quadrature 5VDC RS422 compatible.

Power: Power must be supplied to the interface.

5VDC +/-10% power limited to < 15w.

1	Enc B
2	Enc B'
3	Enc A
4	Enc A'
5	Aux Enc A'
6	Aux Enc A
7	Aux Enc B'
8	Aux Enc B
9	Enc +5V
10	Enc Com
H	Shield




Fig. 4 - JIREH Industries pin out configuration

2.2. Compatible Components

The components listed do modify the product specifications (*i.e. intended use, power requirements, etc.*) from those of the base system. The specifications listed here supersede those of the base system.

2.2.1. Low Profile Probe Holder Frame CXG004-

2.2.1.1 Intended Use

The Low Profile Probe Holder Frame is intended to be mounted in the NAVIC's swivel mount to provide mounting of multiple probe holders. Its use limits the NAVIC's operation to inspection surfaces that are either flat or driven on in the circumferential direction.




Fig. 5 - Low profile probe holder frame

2.2.1.2 Operating Limits

Category	Parameter	Specification
Inspection Surface	Minimum OD, longitudinal driving	Not recommended
Maximum number of probe holders	Slip joint probe holders	4

2.2.2. Vertical Probe Holder Frame CXG007-

2.2.2.1 Intended Use

The Vertical Probe Holder Frame is intended to be mounted in the NAVIC's swivel mount to provide mounting of multiple probe holders. Its use limits the NAVIC's operation to inspection surfaces that are either flat or driven on in the circumferential direction.




Fig. 6 - Vertical probe holder frame

2.2.2.2 Operating Limits

Category	Parameter	Specification
Inspection Surface	Minimum OD, longitudinal driving	Not recommended
Maximum number of probe holders	Vertical probe holders	6

2.2.3. Pivoting Probe Holder Frame CXG013-

2.2.3.1 Intended Use

The Pivoting Probe Holder Frame is intended to be mounted in the NAVIC's swivel mount to provide mounting of multiple probe holders. Its use limits the NAVIC's operation to the operating limits shown below.




Fig. 7 - Pivoting probe holder frame

2.2.3.2 Operating Limits

Category	Parameter	Specification
Inspection Surface	Minimum OD, longitudinal driving	305 mm (12 in)
Maximum number of probe holders	Vertical probe holders	6

2.2.4. Frame Bar BG0038-

2.2.4.1 Intended Use

The Frame Bar is intended to be mounted in the NAVIC's swivel mount to provide mounting of multiple probe holders. Its use limits the NAVIC's operation to inspection surfaces that are either flat or driven on in the circumferential direction.




Fig. 8 - Frame bar

2.2.4.2 Operating Limits

Category	Parameter	Specification
Inspection Surface	Minimum OD, longitudinal driving	Not recommended
Maximum number of probe holders	Slip joint probe holders	2
	Vertical probe holders	2
	Heavy duty vertical probe holders	2

2.2.5. Preamp Bracket
CES029-

2.2.5.1 Intended Use

The Preamp Bracket is intended to mount objects, such as preamps, splitters, etc., on a probe holder frame or frame bar that is mounted to the NAVIC crawler. The mounted object is attached to the NAVIC with a lanyard or probe cables strong enough to prevent the object from falling, should the straps or screws that hold it to the bracket fail. Also, if the object is mounted with straps, it is to have smooth edges so as not to cut the straps.




Fig. 9 - Preamp bracket

2.2.5.2 Operating Limits

Category	Parameter	Specification
Preamp Bracket	Maximum weight of mounted object	1.36 kg (3 lb)
Scanner	Required radial clearance (handles removed, circumferential driving)	Dependent on object mounted on Preamp Bracket

2.2.6. NAVIC Backpack
CXS077

2.2.6.1 Intended Use

The NAVIC Backpack is intended to mount objects, such as preamps, splitters, etc. on the NAVIC crawler. The mounted object is to be attached to the NAVIC with a lanyard or probe cables strong enough to prevent the object from falling, should the straps fail. Also, the object is to have smooth edges so as not to cut the strap.




Fig. 10 - NAVIC backpack

2.2.6.2 Operating Limits

Category	Parameter	Specification
NAVIC Backpack	Maximum weight of mounted object	1.36 kg (3 lb)
Scanner	Required radial clearance	Dependent on object mounted to Backpack

2.2.7. NAVIC Camera Mount
CXG067

2.2.7.1 Intended Use

The NAVIC Camera Mount is intended to mount any small action camera on the NAVIC crawler.




Fig. 11 - NAVIC camera mount

2.2.7.2 Operating Limits

Category	Parameter	Specification
Camera	Maximum weight	0.5 kg (1.1 lb)
	Required mounting hole	1/4 in - 20 thread
Scanner	Required radial clearance	Dependent on camera size

2.2.8. Battery Powered Optical Guide
CXS080

2.2.8.1 Intended Use

The Battery Powered Optical Guide is intended to provide a point of reference useful for guiding the NAVIC along a given path (*i.e. a weld cap*). It is intended to be mounted in the dovetail groove of any probe holder frame or frame bar.




Fig. 12 - Battery powered optical guide

2.2.8.2 Operating Environment

Category	Parameter	Specification
Scanner	Required radial clearance	Dependent on mounted orientation of Battery Powered Optical Guide

2.2.8.3 Power Requirements

Power requirements: 1 AA battery

2.2.8.4 Environmental Sealing

IP64

2.2.9. Medium Temperature Add-On Kit
CXG031-

2.2.9.1 Intended Use

The Medium Temperature Add-On Kit allows the NAVIC to operate on inspection surfaces that are hotter.




Fig. 13 - Automated crawler medium temperature add-on kit

2.2.9.2 Operating Limits

Category	Parameter	Specification
Inspection surface	Maximum surface temperature	150°C (302°F)
Scanner	Required radial clearance	Dependent on object mounted to Backpack

2.3. Child Products

The products listed in this section integrate with the NAVIC to perform certain tasks. Their use modifies the product specifications (i.e. intended use, power requirements, etc.) from those of {this product}. These products have a User Manual of their own which should also be referred to for their product specifications.

2.3.1. Motorized Couplant Pump CMA015

The Motorized Couplant Pump is a powered pumping unit used to supply couplant fluid to scanning equipment.




Fig. 14 - Motorized couplant pump

2.3.2. Motorized Raster Arm CWG002-

Available in various lengths, the Motorized Raster Arm can carry many different probes for various types of corrosion scans. The Motorized Raster Arm is intended to be mounted in the NAVIC's swivel mount.




Fig. 15 - Motorized raster arm

2.3.3. Corrosion Actuated Probe Lift CXG030-

The Corrosion Actuated Probe Lift allows the user to raise and lower a corrosion thickness probe holder remotely from the handheld controller. This allows the probe to avoid obstacles and large welds, preventing damage and unnecessary wear to the probe. The Corrosion Actuated Probe Lift is intended to be mounted in the NAVIC's swivel mount.




Fig. 16 - Corrosion actuated probe lift

2.3.4. Preamp CXG032

The Preamp is used to amplify the return signal from an ultrasonic transducer and improve the signal-to-noise ratio for transmission over long cables.




Fig. 17 - Preamp

2.3.5. Optical Guide CXG035

The Optical Guide mount's to any dovetail attached to a motorized crawler. The Optical Guide provides a green colour, point of reference for guiding scanners along a given path (*i.e. a weld*).




Fig. 18 - Optical guide

2.3.6. Tracker DRG001

The Tracker uses advanced laser guidance to follow elevated profiles (*i.e. a weld*) on a ferrous surface. It is intended to be mounted in the dovetail groove of any probe holder frame or frame bar.




Fig. 19 - Tracker

2.3.7. Battery Kit DVG001-

The battery provides portable power to the crawler.





Fig. 20 - Battery

DEFINITIONS


3.1. Definition of Symbols



Instructions to 'look here' or to 'see this part'.



Denotes movement. Instructing user to carry out an action in a specified direction.



Indicates alignment axis



Alerts the user that the view has changed to a reverse angle

3.2. Definitions of Terms




Fig. 21 - Circumferential scanning




Fig. 22 - Longitudinal scanning

Circumferential

Direction of scan travel is around the circumference of the pipe/tube (Fig. 21).

Longitudinal

Direction of scan travel is lengthwise of the pipe/tube (Fig. 22).

3.3. Safety Symbols

The following safety symbols might appear on the product and in this document. Read and understand their meaning below:



General warning symbol

This symbol is used to alert the user to potential hazards. All safety messages that follow this symbol shall be obeyed to avoid possible harm or material damage.



Shock hazard caution symbol

This symbol is used to alert the user to potential electric shock hazards. All safety messages that follow this symbol shall be obeyed to avoid possible harm.



Laser warning symbol

This symbol is used to alert the user to potential laser hazards. All safety messages that follow this symbol shall be obeyed to avoid possible harm or material damage.

3.4. Safety Signal Words

The following safety signal words might appear in this document. Read and understand their meaning below:

DANGER!

The DANGER signal word indicates an imminently hazardous situation. It calls attention to a procedure, practice, or the like that if not correctly performed or adhered to will result in death or serious personal injury. Do not proceed beyond a DANGER signal word until the indicated conditions are fully understood and met.

WARNING!

The WARNING signal word indicates a potentially hazardous situation. It calls attention to a procedure, practice, or the like that if not correctly performed or adhered to could result in death or serious personal injury. Do not proceed beyond a WARNING signal word until the indicated conditions are fully understood and met.

CAUTION!

The CAUTION signal word indicates a potentially hazardous situation. It calls attention to a procedure, practice, or the like that if not correctly performed or adhered to may result in minor or moderate personal injury, material damage, particularly to the product, destruction of part or all of the product, or loss of data. Do not proceed beyond a CAUTION signal word until the indicated conditions are fully understood and met.

SYSTEM COMPONENTS

4.1. Base System Components

4.1.1. NAVIC Crawler CXA016-



WARNING! MAGNETIC MATERIAL. The wheels of the crawler produce an extremely strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics. People with pacemakers or ICD's must stay at least 75 cm (30 in) away.

The NAVIC Crawler is a modular, motorized, and steerable scanner that can carry various attachments for scanning and inspection applications. The NAVIC is capable of performing a wide range of inspections on circumferential or longitudinal ferrous materials.




Fig. 23 - NAVIC (crawler)

4.1.1.1 Right Drive Module

The right drive module includes the encoder, umbilical connections and accessory mounting point. When connected to the left drive module, the **NAVIC** scanner can steer on an inspection surface.




Fig. 24 - Right drive module

NOTE: The ability to effectively steer the crawler in the circumferential direction decreases as pipe diameters decrease below 300 mm (12 in).

It is possible to use the right drive module independently to carry out weld scanning when steering is not required or when overall scanner size is a concern.

4.1.1.1.1 Encoder




Fig. 25 - Encoder wheel

The right drive module includes an independent encoder wheel. This encoder wheel provides accurate encoding even in the event of drive wheel slip.

The spring-loaded encoder wheel maintains scan surface contact through all listed scan diameter sizes (see "Operating Limits" on page 4). Adjustment of the encoder wheel is not required.

4.1.1.2 Left Drive Module

The left drive module is only used with the right drive module. Combining both modules allows the **NAVIC** scanner to steer on an inspection surface.

NOTE: *Steering is limited on smaller diameter inspection surfaces.*




Fig. 26 - Left drive module

4.1.2. Power Controller CXA040-



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.



WARNING! There are no user serviceable components inside the power controller. Dangerous voltages can be present inside the case. Do **NOT** open. Return to manufacturer for repair.

The Power Controller is an essential component providing the NAVIC with reliable power. It offers two power options, including a standard power supply that can be configured for various plug styles, and compatibility with battery power (sold separately).




Fig. 27 - Power controller




Fig. 28 - Power controller

The power controller accepts 25-45VDC power from the AC/DC power supply or battery. A start/stop safety circuit and physical **ON** and **OFF** push-buttons are integrated into the power controller.

1	AC/DC power supply	Connect the plug from a properly grounded source. Use an IEC320 cord approved for AC/DC power supply.
2	Release button	Unlatch the AC/DC power supply or battery from the power controller.
3	Power button	Activate system power by pressing <i>(and releasing)</i> the silver button.
4	Stop button	The red stop button latches down when pressed. This stop button shuts down the system. Twist the stop button clockwise to return to the released position. This must be done before power can be activated.
5	Scanlink™ connector	Connection for Scanlink devices.
6	CTRL socket	Connection for the auxiliary cable.
7	ENC socket	Connection for the encoder cable.
8	Status LCD	Power controller status display.
9	Umbilical connection	Connection for the umbilical.

In the event of a break in the stop circuit *(the stop circuit runs through the power controller cable, umbilical and the crawler's stop button)*, power will shut off.

4.1.2.1 AC/DC Power Supply



WARNING! ELECTRICAL CORDS CAN BE HAZARDOUS. Misuse can result in **FIRE** or **DEATH** by **ELECTRICAL SHOCK**. Inspect thoroughly before each use. Do **NOT** use if damaged. Do **NOT** use when wet. Keep away from water. Do **NOT** drive, drag or place objects over cord.

The **1** AC/DC power supply *(Fig. 28)* connects the power controller to a suitable 100-240VAC, 50/60Hz grounded power source capable of supplying a minimum of 5 amps.

The safety of the power controller relies on the provision of a proper ground connection.

In environments with moisture present, a GFCI (*Ground Fault Circuit Interrupter*) must be used to ensure operator safety.

NOTE: Some generators or DC-AC inverters may introduce significant levels of noise to the system. This may degrade overall system performance or reduce the system life expectancy. The use of generators or DC-AC inverters is not recommended and is used at the operator's risk.

4.1.3. Umbilical UMA030-



WARNING! FALLING OBJECT HAZARD.

Ensure the umbilical can freely uncoil during operation and does not become snagged. If umbilical becomes snagged, the crawler may fall and **SEVERE INJURY** or **DEATH** could result.

The NAVIC relies on the umbilical to provide all the necessary power, network distribution, and encoder signals. The NAVIC Umbilical is specifically designed to connect the Crawler to the Power Controller, enabling uninterrupted power and data transmission during inspections.




Fig. 29 - Umbilical




Fig. 30 - Umbilical

The circuitry is incorporated into the umbilical to protect or isolate all signals. The umbilical provides separation between the power controller and the crawler. Various umbilical lengths are available, from 5 m to 30 m (16.4 ft to 98.4 ft) long.

4.1.3.1 Umbilical Connections




Fig. 31 - Umbilical (crawler side)




Fig. 32 - Umbilical (cable side)

Multiple 4-pin and 8-pin receptacles are located on both ends of the umbilical. Any 4-pin connector can be plugged into any 4-pin receptacle. Any 8-pin connector can be plugged into any 8-pin receptacle.

System power and network wiring are identical on each type of plug. The only difference is that the 8-pin receptacle encoder pin wiring is unique to either the primary **4 X ENC** (Fig. 31) or secondary **2 Y ENC** (Fig. 31) encoder axis. The **3** unlabeled receptacle (Fig. 31) contains no encoder wiring.

TIP: Cables may be plugged into any 8-pin receptacle. This only affects which encoder signal is transmitted to the umbilical's 10-pin encoder output connector plug.

1	4-pin accessory connector	Typical usage: Optical guide, Tracker, Corrosion actuated probe lift, Handheld controller
2	8-pin expansion connector	The module connected to the Y-ENC 8-pin port will transmit encoder signals through the umbilical as the 2 nd encoder axis. Typical usage: Optional motorized raster arm
3	8-pin connector	The unlabeled 8-pin port does not support encoder signals. Typical usage: Left drive module
4	8-pin expansion connector	The module that is connected to the X-ENC 8-pin port transmits encoder signals through the umbilical as the 1 st encoder axis. Typical usage: Right drive module

5 Stop button

(see "Stop Button" on page 25).

6 4-pin accessory connector

Typical usage: Optical guide, Tracker, Corrosion actuated probe lift, Handheld controller

4.1.3.2 Stop Button




Fig. 33 - Stop

The **5** red button (Fig. 31) located on the umbilical provides a stop button to the entire system. When pressed, all power to the **NAVIC** system will disengage.

To restore system power, it is necessary to press the power button located on the power controller (see "Power Controller" on page 21).

NOTE: Terminating system power may cause the crawler to freewheel down when operating in a vertical orientation.

4.1.3.3 Encoder Signal Isolation

The umbilical contains a built-in circuit which buffers encoder signals in addition to providing isolation and protection to user instrumentation. The isolator requires 5VDC from the user's instrument, and this is built into the supplied encoder cables.

4.1.4. Handheld Controller DMA006



WARNING! MAGNETIC MATERIAL. The handheld controller contains magnetic material. Those with pacemakers or ICD's must stay at least 10 cm (4 in) away.



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.



With the Handheld Controller, users can control and adjust every aspect of your crawler's operation. The controller's color touch screen displays an intuitive and easy-to-use operating system, complete with haptic feedback. The joysticks on the controller provide precise driving and steering control.

User settings and scan information are edited using the handheld controller. The handheld controller is connected to the power controller or umbilical with the auxiliary cable.

The handheld controller utilizes a resistive touch screen. Care should be taken not to use sharp or gritty objects on the screen as the touch membrane can scratch. If the screen is damaged, all programmed functions can still be accessed using the D-pad.

NOTE: Do **NOT** connect the handheld controller while the system is activated.




Fig. 35 - Handheld controller




Fig. 34 - Handheld controller

4.1.5. Auxiliary Cable UMA017-

The auxiliary cable connects the handheld controller to the power controller. 36VDC and network signals are used in the cable.

Both auxiliary cable connectors are identical and interchangeable. The cable may be plugged into the 4-pin receptacle on the power controller or the crawler's umbilical.




Fig. 36 - Auxiliary cable

4.1.6. J300 Encoder Cable UMA025-

The encoder cable connects the **NAVIC** system to the user's instrument. This cable allows the transmission of two-axis position signals from the **NAVIC** to the instrument. The encoder cable also provides 5VDC from the user's instrument to the encoder isolation circuitry.

Various encoder styles are available for various instruments.




Fig. 37 - J300 Encoder cable

4.1.7. Installation/Removal Mat AAS061



WARNING! MAGNETIC MATERIAL. The installation/removal mat contains magnetic material. Those with pacemakers or ICD's must stay at least 10 cm (4 in) away.

The installation/removal mat is used to install and remove motorized magnetic-wheeled scanners from the inspection surface. A motorized scanner can drive on/off the mat while the integrated magnets in the mat hold it firmly in place on the inspection surface. The scanner installation mat can be used on both round and flat surfaces.




Fig. 38 - Installation/removal mat

4.1.8. Lifting Sling CXA009

The lifting sling attaches to the crawler, providing an attachment point for tethers. When operating a **NAVIC** at a height greater than 2 m (6 ft), the crawler **MUST** be tethered with a proper tether system to prevent the crawler from falling (see "No Entry Fall Zone" on page 38).




Fig. 39 - Lifting sling

4.1.9. Irrigation Kit CMG009-

The irrigation kit provides a variety of hoses, fittings, connectors, and splitters commonly used during non-destructive inspection.




Fig. 40 - Irrigation kit

4.1.10. Cable Management CXS046-

The cable management provides a means of protecting and organizing cables, tubes and hoses.




Fig. 41 - Cable management

4.1.11. Cap: NAVIC Hinge Cover CXS066

Prevent contamination and damage to the NAVIC's connection pivots. When the left and right modules are separated, it is imperative that the connection pivots remain free of dirt, sand, mud, etc. (see *"Connecting/ Disconnecting Left and Right Modules"* on page 67 for additional details).




Fig. 42 - Cap: NAVIC hinge cover

4.1.12. Plug CX0174

Prevent contamination and damage to the NAVIC's connection pivots. When the left and right modules are separated, it is imperative that the connection pivots remain free of dirt, sand, mud, etc. (see "Connecting/ Disconnecting Left and Right Modules" on page 67 for additional details)




Fig. 43 - Plug

4.1.13. Battery DVA001

The battery is compatible with the power controller and will power the NAVIC system for hours at a time.




Fig. 44 - Battery

4.1.14. Charger and Power Adapter DVG002-




Fig. 45 - Charger and Power Adapter

4.1.15. Tools

Several tools are included for various scanner and accessory adjustments. (see "Included Tools" on page 37 for additional details)

4.1.16. Cases

Depending on the configuration selected at the time of purchase. This will determine the types and amount of cases included with the system.

4.2. Compatible Components

4.2.1. Low Profile Probe Holder Frame CXG004-

The low profile probe holder frame carries up to four probes during limited access circumferential weld inspection. Removal of the **NAVIC** handles and using the low profile probe holder frame allow inspection when radial clearance is limited.




Fig. 46 - Low profile probe holder frame

4.2.2. Vertical Probe Holder Frame CXG007-

The vertical probe holder frame carries up to six probes during circumferential weld inspection. Available in many of configurations and lengths, the vertical probe holder frame attaches to the front of the **NAVIC** crawler.




Fig. 47 - Vertical probe holder frame

4.2.3. Pivoting Probe Holder Frame CXG013-

The pivoting probe holder frame carries up to six probes during longitudinal weld inspection. Available in many configurations and lengths, the pivoting probe holder frame may also be used for circumferential weld inspection.




Fig. 48 - Pivoting probe holder frame

4.2.4. Frame Bar BG0038-

Frame bars use dovetail grooves to attach probe holders and accessories. Available in various length. Available in various lengths.




Fig. 49 - Frame bar

4.2.5. Slip Joint Probe Holder PHA012-

The slip joint probe holder is generally used during limited access inspection. The low profile design requires minimal radial clearance. The slip joint probe holder is designed to carry many different types of probes and wedges. It is available with various types of yokes, arms and pivot buttons.




Fig. 50 - Slip joint probe holder

4.2.6. Vertical Probe Holder PHA015-

The vertical probe holder is designed to carry many different types of probes and wedges. Available with various types of yokes, arms and pivot buttons. The vertical probe holder features several different adjustment options for each unique probe/wedge setup.




Fig. 51 - Vertical probe holder

4.2.7. Heavy Duty Vertical Probe Holder PHS043-

The heavy duty vertical probe holder is designed to carry larger probes. Available with various arm, yoke and pivot buttons, the heavy duty vertical probe holder exerts more downforce on a large footprint probe/wedge.




Fig. 52 - Heavy duty vertical probe holder

4.2.8. Corrosion Thickness Probe Holder PHS046- / PHS056-

The corrosion thickness probe holder carries various probes for the purpose of corrosion inspection and is available with either a flat or curved wear plate.




Fig. 53 - Corrosion thickness probe holder

4.2.9. HydroFORM Cart PHS044

The HydroFORM Cart carries an Olympus HydroFORM™ probe. The HydroFORM cart is designed to be used with the heavy duty vertical probe holder.




Fig. 54 - HydroFORM cart

4.2.10. Preamp Bracket CES029-

The preamp mounts to any dovetail groove. It is compatible with most standard preamps.




Fig. 55 - Preamp bracket

4.2.11. NAVIC Backpack CXS077

The **NAVIC** backpack provides a means of carrying equipment/hardware on a **NAVIC** crawler.




Fig. 56 - NAVIC backpack

4.2.12. NAVIC Camera Mount CXS067

The **NAVIC** camera mount provides a mounting point for cameras on a NAVIC crawler.




Fig. 57 - NAVIC camera mount

4.2.13. Battery Powered Optical Guide CXS080

The battery powered optical guide provides a red colour point of reference useful for guiding scanners along a given path (*i.e. a weld*).




Fig. 58 - Battery powered optical guide

4.2.14. Automated Crawler Medium Temperature Add-On Kit CXG031-

The automated crawler medium temperature add-on kit enables a **NAVIC** crawler to operate on an inspection surface with a temperature up to 150°C (302°F).




Fig. 59 - Automated crawler medium temperature add-on kit

4.2.15. Encoder Adapter UMA010-

The encoder adapter changes the scanner's built-in encoder connector style.




Fig. 60 - Encoder adapter

4.2.16. 3-Axis Nozzle Scanner Add-On Kit CXG028-

The 3-axis nozzle scanner add-on kit mounts to the right drive module of the **NAVIC** crawler to offer encoded inspection of nozzle and fitting welds.




Fig. 61 - 3-axis nozzle scanner add-on kit

4.3. Child Products

4.3.1. Motorized Couplant Pump CMA015

The motorized couplant pump is a powered pumping unit that supplies couplant fluid to the scanning surface.




Fig. 62 - Motorized couplant pump

4.3.2. Motorized Raster Arm CWG002-

The motorized raster arm is available in various lengths and offers programmable speed and travel settings.




Fig. 63 - Motorized raster arm

4.3.3. Corrosion Actuated Probe Lift CXG030-

The corrosion actuated probe lift allows the probe to be lifted from the inspection surface, preserving the probe's life and allowing travel over small obstacles and large welds. The corrosion actuated probe lift is compatible with various probe styles and is available with either a flat or curved wear plate.




Fig. 64 - Corrosion actuated probe lift

4.3.4. Preamp Kit CXG032-

The preamp is used to amplify the return signal from an ultrasonic transducer and improve the signal-to-noise ratio for transmission over long cables.




Fig. 65 - Preamp kit

4.3.5. Optical Guide CXG035

The optical guide mounts to any dovetail and provides a green colour point of reference useful for guiding scanners along a given path (*i.e. a weld*).




Fig. 66 - Optical guide

4.3.6. Tracker DRG001

The tracker is mounted atop any probe holder frame and uses advanced laser guidance to follow elevated profiles (*i.e. welds*).




Fig. 67 - Tracker

4.3.7. Battery Kit DVG001-

The rechargeable battery provides portable power to the crawler and components (*i.e. motorized raster arm*).




Fig. 68 - Battery

4.4. Tools

4.4.1. Included Tools




Fig. 69 - 3 mm hex driver




Fig. 70 - 3/8 in wrench

The included 3 mm hex driver (*Fig. 69*) is suitable for most typical adjustments within the **NAVIC** system.

Also included in this kit is a 3/8 in wrench (*Fig. 70*), which is used to remove and install probe holder pivot buttons.

The included 3 mm flat driver (*Fig. 71*) helps release the flaps of the motorized raster arm's cable tray.




Fig. 71 - 3 mm flat driver

4.4.2. Optional Tools

Some specialized adjustments require tools that are not included in this kit.




Fig. 72 - 1.5 mm hex wrench




Fig. 73 - 2 mm hex wrench




Fig. 74 - 3 mm hex wrench

PREPARATION FOR USE

5.1. Preparation for Transportation



CAUTION! PINCH / CRUSH HAZARD. BE CAREFUL when passing the **NAVIC** crawler through narrow ferrous (*magnetic*) openings, such as man-holes. The magnetic drive wheels can cause bodily harm if allowed to slam onto the walls of the opening.

5.2. Preparation for Safe Use

5.2.1. No Entry Fall Zone



WARNING! FALLING OBJECT HAZARD. The area below a crawler must be kept clear at all times. A clearly marked **NO ENTRY FALL ZONE** must be cordoned off directly below the area of crawler operation.

The area below a crawler must be kept clear at all times. A clearly marked **NO ENTRY FALL ZONE** must be cordoned off directly below the area of crawler operation, according to the dimensions shown in (Fig. 75).




Fig. 75 - No entry fall zone

Example: If inspecting a tank that is 6 m (20 ft) tall, the No Entry Fall Zone radii must be no smaller than 3 m (10 ft) from the area below the area of crawler operation.

5.2.2. Tether Requirements and Attachment



WARNING! FALLING OBJECT HAZARD.

Failure to comply with the warnings, instructions, and specifications in this manual could result in **SEVERE INJURY** or **DEATH**.

WARNING! Do **NOT** operate or place crawler on a surface higher than 2 m (6 ft) without a proper tether held taut at all times.

WARNING! Hook the tether hook to the provided lifting sling **BEFORE** placing the crawler on the surface to be inspected (*e.g. tank*). **IMPORTANT:** Tether hook must have a safety latch to prevent accidental disconnection.

When used at a height greater than 2 m (6 ft), the **NAVIC** crawler **MUST** be tethered with a proper tether system to prevent the crawler from falling. The tether system must:

- ▶ be capable of safely suspending the crawler from above in case the crawler detaches from the inspection surface;
- ▶ have sufficient capacity to catch and hold a 70 kg (150 lb) load;
- ▶ include a mechanism (*i.e. self retracting inertia reel fall arrester*) or a person to continuously take up the slack in the tether as the crawler moves;
- ▶ include a lifting hook with a safety latch to prevent accidental disconnection. The hook must be free of sharp edges that may cut or abrade the provided lifting sling.

Before placing the crawler on the surface to be inspected (*e.g. tank*), attach the provided lifting sling to the **NAVIC** and then hook the tether hook to the lifting sling.



CAUTION! The overhead attachment point for the tether must be located as close as possible to a location directly above the crawler to minimize dangerous swinging of the crawler should it detach from the inspection surface.

5.2.3. Lifting Sling Setup



WARNING! Carefully inspect the lifting sling for damage prior to each use. Ensure the tether hook does not have sharp edges that may cut the lifting sling.

Secure the lifting sling to the **NAVIC** as indicated here:




Fig. 76 - Lift tether attachment points

1. Lift the two tether attachment points (Fig. 76).




Fig. 77 - Press release button




Fig. 78 - Pull pin from

2. Simultaneously press the pin's release button (Fig. 77) and pull the pin from the shackle (Fig. 78).




Fig. 79 - Align shackle with tether holes




Fig. 80 - Insert pin

3. Slide the shackle around the tether attachment point (Fig. 79).
4. Align the tether attachment point and shackle. Insert the pin while pressing the pin's release button (Fig. 80).




Fig. 81 - Proper shackle setup




Fig. 82 - Incorrect shackle setup

NOTE: Ensure proper orientation of the shackles (Fig. 82).

5.2.4. Lifting Sling Low Profile Setup

The following adjustment allows low profile scanning when required.




Fig. 83 - Proper shackle setup




Fig. 84 - Proper shackle setup

1. The shackle plate (*Fig. 83*), in conjunction with the tether attachment point, provides the necessary clearance for scanning equipment.
2. Reverse the lifting sling and shackles (*Fig. 84*) so that the shackles are free to lay down flat, allowing for a low profile sling setup.

5.3. Preparation of Inspection Surface



WARNING! FALLING OBJECT HAZARD.

The inspection surface must adhere to the conditions outlined in sections “*Intended Use*” on page 3 and “*Operating Environment*” on page 5 of this manual.

- ▶ Remove build-up of scale, and other debris (i.e. dirt, ice) from surface on which the crawler is to drive. Excessive build-up will cause the wheels to lose magnetic attraction which may lead to wheel slippage or crawler detachment.
- ▶ Ensure that no obstructions (*other than standard butt welds*) or voids are in the drive path. Obstructions and voids could cause the crawler to fall if driven into or over.
- ▶ Ensure that there are no patches of non-ferrous material in the drive path of the crawler. If the crawler drives over a non-ferrous patch, it will lose magnetic attraction and will cause the crawler to fall.

5.4. System Connectivity




Fig. 85 - Standard crawler configuration

BOM ID	Description
1	Right drive module
2	Left drive module
3	Scanlink™ cable
4	Encoder cable
5	User instrument
6	Handheld controller
7a	Auxiliary cable
7b	Auxiliary cable (<i>alternate</i>)
8	Umbilical
9	Power controller
10	AC/DC power supply

To configure the **NAVIC** system for scanning, follow these steps:



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Mount and connect the **8** umbilical to **1** right drive module of the crawler.
2. Connect **8** umbilical to **9** power controller.
3. Connect **6** handheld controller to **9** power controller using the **7a** auxiliary cable.

NOTE: The **6** handheld controller may also be connected directly to the **8** umbilical using the **7b** auxiliary cable.

4. Connect **4** encoder cable from the **5** user's instrument to the **9** power controller.
5. Insert **10** AC/DC power supply into the **9** power controller.
6. (see "NAVIC Configurations" on page 45) to set up a particular component.

5.5. NAVIC Configurations

5.5.1. Single Drive Module with Frame Bar




Fig. 86 - Single drive module configuration

BOM ID	Description
1	Frame bar
2	Right drive module
3	Umbilical

To configure the **NAVIC** system for scanning using a single drive module with a frame bar, follow these steps:



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Separate the left and right drive modules (see “Connecting/Disconnecting Left and Right Modules” on page 67).
2. Mount and connect the ③ umbilical to ② right drive module.
3. Attach a configured ① frame bar to the ② right drive module (see “Swivel Mount” on page 64).

5.5.2. Crawler with Corrosion Actuated Probe Lift




Fig. 87 - Standard NAVIC configuration with corrosion actuated probe lift

BOM ID	Description
1	Corrosion actuated probe lift
2	Auxiliary cable
3	Right drive module
4	Left drive module
5	Umbilical

To configure the **NAVIC** system for single-line corrosion scanning using dual drive modules with a corrosion actuated probe lift, follow these steps (see “Corrosion Actuated Probe Lift” user manual):



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Mount and connect the **5** umbilical to **3** right drive module of the crawler.
2. Attach the **1** corrosion actuated probe lift (see “Corrosion Actuated Probe Lift” user manual) to the **3** right drive module (see “Swivel Mount” on page 59).
3. Connect the **2** auxiliary cable to the **1** corrosion actuated probe lift and to the **5** umbilical.

5.5.3. Crawler with Multiple Probe Holders

5.5.3.1 Vertical Probe Holder Frame




Fig. 88 - Standard crawler configuration with vertical probe holder frame

BOM ID	Description
1	Tracker
2	Tracker cable
3	Vertical probe holder frame
4	Right drive module
5	Left drive module
6	Umbilical

To configure the **NAVIC** system for scanning using dual drive modules with a vertical probe holder frame, follow these steps (see “Vertical Probe Holder Frame - Flat or Circumferential Only” on page 106):



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Mount and connect the **6** umbilical to **4** right drive module of the crawler.
2. Attach a configured **3** vertical probe holder frame (see “Vertical Probe Holder Frame - Flat or Circumferential Only” on page 106) to the crawler (see “Swivel Mount” on page 59).
3. Optional:
 - ▶ Attach the **1** tracker (see “Tracker” user manual) to the front of the **3** vertical probe holder frame.
 - ▶ Connect the **2** tracker cable to the **6** umbilical’s 4-pin expansion connector.

5.5.3.2 Low Profile Probe Holder Frame




Fig. 89 - Standard crawler configuration with low profile probe holder frame

BOM ID	Description
1	Low profile probe holder frame
2	Right drive module
3	Left drive module
4	Umbilical

To configure the **NAVIC** system for scanning using dual drive modules with a low profile probe holder frame, follow these steps (see “*Low Profile Probe Holder Frame - Flat or Circumferential Only*” on page 110):



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Mount and connect the **4** umbilical to **2** right drive module of the crawler.
2. Attach a configured **1** low profile probe holder frame (see “*Low Profile Probe Holder Frame - Flat or Circumferential Only*” on page 110) to the crawler (see “*Swivel Mount*” on page 59).

5.5.3.3 Pivoting Probe Holder Frame




Fig. 90 - Standard crawler configuration with pivoting probe holder frame

BOM ID	Description
1	Tracker
2	Tracker cable
3	Pivoting probe holder frame
4	Right drive module
5	Left drive module
6	Umbilical

To configure the **NAVIC** system for scanning using dual drive modules with a pivoting probe holder frame, follow these steps (see “*Pivoting Probe Holder Frame*” on page 114):



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Mount and connect the **6** umbilical to **4** right drive module of the crawler.
2. Attach a configured **3** pivoting probe holder frame (see “*Pivoting Probe Holder Frame*” on page 114) to the crawler (see “*Swivel Mount*” on page 59).
3. Optional:
 - ▶ Attach the **1** tracker (see “*Tracker*” user manual) to the front of the **3** pivoting probe holder frame.
 - ▶ Connect the **2** tracker cable to the **6** umbilical’s 4-pin expansion connector.

5.5.3.4 Flange




Fig. 91 - Standard crawler configuration with pivoting probe holder frame configured for flange scanning

BOM ID	Description
1	Flange probe holder frame
2	Right drive module
3	Left drive module
4	Umbilical

To configure the **NAVIC** system for scanning using dual drive modules with a pivoting probe holder frame configured for flange scanning, follow these steps (see “Pivoting Probe Holder Frame - Flange Scanning” on page 118):



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Mount and connect the **4** umbilical to **2** right drive module of the crawler.
2. Attach a configured **1** flange probe holder frame (see “Pivoting Probe Holder Frame - Flange Scanning” on page 118) to the crawler (see “Swivel Mount” on page 59).

5.5.4. 3-Axis Nozzle Scanning




Fig. 92 - Single module with nozzle scanner configuration

BOM ID	Description	BOM ID	
1	Slider PPS encoder	6	User instrument
2	Encoded skew vertical P.H.	7	Handheld controller
3	Right drive module	8a	Auxiliary cable
4	3-axis encoder cable	8b	Auxiliary cable (alternate)
5	Umbilical	9	Power controller
		10	AC/DC power supply

To configure the NAVIC system for scanning using a single module and a 3-axis nozzle scanning system, follow these steps (see “3-Axis Nozzle Scanning” on page 87):



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.

1. Separate the crawler's drive modules (see “Connecting/Disconnecting Left and Right Modules” on page 67).
2. Mount and connect the **5** umbilical at a 90° angle to **3** right drive module.
3. Connect the **5** umbilical to the **9** power controller.
4. Connect the **7** handheld controller to the **9** power controller using the **8a** auxiliary cable.

NOTE: The **7** handheld controller may also be connected directly to the **5** umbilical using the **8b** auxiliary cable.

5. Mount the appropriate 3-axis nozzle configuration to the swivel mount of the crawler.
6. Connect the **4** 3-axis encoder cable to the encoder cables of the **2** encoded skew vertical probe holder and the **1** slider pps encoder.
7. Connect the opposite end of the **4** 3-axis encoder cable to the **6** user's instrument and to the **9** power controller.

5.6. Right Drive Module

5.6.1. Swivel Mount




Fig. 93 - Frame bar installation




Fig. 94 - Swivel mount angle

Located at the front of the right drive module, the swivel mount is used to connect scanning accessories such as a motorized raster arm or probe frame system.

Rotate the two black wing knobs (*Fig. 93*) to loosen the dovetail jaws. Slide the accessory's frame bar along the dovetail jaws. Rotate the two black wing knobs to clamp the frame system/raster arm in place.




Fig. 95 - Align dovetail jaws




Fig. 96 - Mount frame bar

Alternatively, accessories can also be mounted straight to the swivel mount. Rotate the black wing knobs aligning the dovetail jaws with the mount's grooves (*Fig. 95*). Press the frame bar or accessory to the swivel mount (*Fig. 96*) and tighten the black wing knobs.

The swivel mount utilizes two levers (*Fig. 94*) to lock the swivel mount at the desired angle.




Fig. 97 - Pivot swivel mount

The etched line (Fig. 97) is to be used to align the front swivel mount to a horizontal position (Fig. 98).




Fig. 98 - Align swivel mount with etched line

5.6.2. Umbilical



WARNING! FALLING OBJECT HAZARD.

For operating at heights greater than 2 m (6 ft), ensure the umbilical strain relief is aligned according to the below instructions and never points upwards as shown in (Fig. 101). The crawler could fall.

SEVERE INJURY or **DEATH** could result.




Fig. 99 - Align umbilical mount




Fig. 100 - Incorrect use




Fig. 101 - Incorrect use

1. For scanning at heights greater than 2 m (6 ft), the umbilical must be set parallel to the scanning surface (Fig. 99).

2. Do not have the umbilical pivoted away from the inspection surface (*Fig. 100*).
3. Ensure the umbilical strain relief never points downwards during operation (*Fig. 101*).




Fig. 102 - Connect to umbilical




Fig. 103 - Align with drive module mount

4. Connect the right drive module's connector to the umbilical (*Fig. 102*).
5. Align the umbilical to the umbilical mount of the drive module (*Fig. 103*).




Fig. 104 - Tighten knob




Fig. 105 - Adjust umbilical mount angle

6. Fasten the umbilical to the crawler's umbilical mount by tightening the black wing knob (*Fig. 104*).
7. Unlock the umbilical mount lock lever, align the umbilical parallel to the scan surface (*Fig. 106*), and lock (*Fig. 105*).




Fig. 106 - Align umbilical parallel to scan surface

5.6.3. Handle

The handle is removable to achieve low profile scanning.

To remove the handle:

Lift the handle lock latch (Fig. 107). Pivot the handle down (Fig. 108) and then pull the handle up to remove from the drive module (Fig. 109).

To reinstall the handle, reverse the preceding steps.




Fig. 107 - Lift handle lock latch




Fig. 108 - Pivot handle nose down




Fig. 109 - Lift handle from module

5.6.4. Dovetail Accessory Mount

Affix optional accessories to the crawler, such as a **NAVIC** backpack, using the dovetail accessory mount.




Fig. 110 - Dovetail accessory mounts

5.7. Left Drive Module

5.7.1. Swivel Mount

Located at the front of the left drive module, the swivel mount is used to connect scanning accessories such as a motorized raster arm or probe frame system.




Fig. 111 - Frame bar installation




Fig. 112 - Swivel mount angle

Rotate the two black wing knobs (*Fig. 111*) to loosen the dovetail jaws. Slide the accessory's frame bar along the dovetail jaws. Rotate the two black wing knobs to clamp the frame system/raster arm in place.

The front mount pivots freely (*Fig. 112*) and cannot be locked in a fixed position. When a frame bar is connected to both dovetail mounts on the two modules, this free movement allows the scanner to flex while steering.

TIP: Alternate mounting procedure is possible (see "Swivel Mount" on page 59 for additional details).

5.7.2. Umbilical Connection




Fig. 113 - Connect to umbilical

1. Connect the left drive module's connector to the umbilical (see *"Umbilical"* on page 23 for additional details).

5.7.3. Handle

(see *"Handle"* on page 62)

5.7.4. Dovetail Accessory Mount

(see *"Dovetail Accessory Mount"* on page 63)

5.8. Handheld Controller



WARNING! MAGNETIC MATERIAL. The handheld controller produces a strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics.



People with pacemakers or ICD's must stay at least 10 cm (4 in) away.



CAUTION! DO NOT DISCONNECT UNDER LOAD. Shut off power before connection or disconnecting. Permanent damage to electronics could occur.



5.8.1. Magnetic Mounts

Magnetic mounts on the rear of the handheld controller assist in preventing the handheld controller from falling.




Fig. 114 - Mount to ferrous surfaces

5.8.2. Connecting/Disconnecting Left and Right Modules



CAUTION! PINCH POINT HAZARD. Keep fingers clear of pinch points when connecting/disconnecting left and right modules.

TIP: This operation is best performed with two people.




Fig. 115 - Press release pin




Fig. 116 - Press pin and rotate modules

1. Locate the release pin at the bottom of the **NAVIC** (Fig. 115). Using the supplied 3 mm hex driver, press the pin while rotating the two modules (Fig. 116).




Fig. 117 - Rotate modules to 90°




Fig. 118 - Pull modules apart

2. Once the two modules are 90° perpendicular (Fig. 117), gently pull the two modules apart (Fig. 118).

3. Label the left drive module with a magnetic warning that is clearly visible.



WARNING! MAGNETIC MATERIAL. The wheels of the crawler produce an extremely strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics. People with pacemakers or ICD's must stay at least 75 cm (30 in) away.




Fig. 119 - Use cap on connection pivot




Fig. 120 - Use cap on connection pivot

4. Always use the provided cap and plug to protect the connection pivots from dirt, dust, mud, etc.

NOTE: When modules are separated. It is imperative that the connection pivots remain free of dirt, sand, mud, etc. If contamination of the pivots occurs, clean the pivots thoroughly. Once the pivot connections are completely free of debris, apply a liberal amount of anti-seize compound (e.g. Kopr Kote®) to the connection pivots of both modules.

5.8.3. Probe Holders

5.8.4. Vertical Probe Holder

- A Latch
- B Probe Holder Adjustment Knob
- C Vertical Adjustment Knob
- D Pivot Buttons
- E Probe Holder Arms
- F Yoke
- G Probe Holder Arm Adjustment Knob
- H Transverse Adjustment Screw
- I Frame Bar




Fig. 121 - Vertical probe holder

5.8.4.1 Probe Holder Setup

To mount a UT wedge in the probe holder, follow these steps:




Fig. 122 - Adjust on frame bar




Fig. 123 - Vertical adjustment




Fig. 124 - Place buttons

1. The probe holder adjustment knob allows the probe holder to be attached to a frame bar and adjusts horizontal positioning (*Fig. 122*).
2. The vertical adjustment knob allows the vertical probe holder height adjustment (*Fig. 123*).
3. Position the pivot buttons where necessary. When a narrow scanning footprint is required, use the pivot button holes closest to the yoke (*Fig. 124*).

TIP: Probe pivoting may be impeded when closer to the yoke.




Fig. 125 - Adjust inner arm




Fig. 126 - Adjust outer arm




Fig. 127 - Tighten arm knob

4. Position the wedge on the inner probe holder arm (Fig. 125).

TIP: The probe holder yoke can accommodate many different probe and wedge sizes of varying widths. It is best to centre the wedge with the yoke's pivot axis. This can reduce wedge 'rocking' when scanning. Position the inner probe holder arm accordingly (Fig. 125) using the supplied 3 mm hex driver (Fig. 69).

5. Loosen the probe holder arm adjustment knob (Fig. 126) and slide the probe holder arm along the yoke pinching the wedge in place.
6. Tighten the probe holder arm adjustment knob (Fig. 127).

5.8.4.2 Probe Holder Vertical Adjustment

To adjust the probe holder vertically, follow these steps:




Fig. 128 - Latch probe holder




Fig. 129 - Lower toward scan surface

1. Ensure the probe holder is in the latched upper position. Lift the probe

holder until the latch is fully exposed and snaps out to lock (Fig. 128).

2. Loosen the vertical adjustment knob and slide the probe holder down until the wedge is approximately 6 mm ($\frac{1}{4}$ in) above inspection surface.
3. Tighten the vertical adjustment knob (Fig. 129).




Fig. 130 - Press latch button




Fig. 131 - Lower toward scan surface

4. Lift the yoke slightly and press the latch button (Fig. 130), then slowly lower towards scanning surface to apply spring pressure to the wedge (Fig. 131).

TIP: If less spring force is desired, refer to step 2 and place the wedge approximately 20 mm ($\frac{3}{4}$ in) above the inspection surface.

5.8.4.3 Probe Holder Transverse Adjustment

To adjust the probe holder's transverse angle, follow these steps:




Fig. 132 - Loosen 3 mm screw




Fig. 133 - Rotate and tighten




Fig. 134 - Stop post locates 90°

1. Ensure the probe holder is in the latched upper position (Fig. 128).

2. Using the supplied 3 mm hex driver loosen the transverse adjustment screw (*Fig. 132*) and rotate the yoke about the vertical shaft achieving the desired angle.
3. Tighten the transverse adjustment screw (*Fig. 133*).

To return the transverse adjustment to neutral (90°). The probe holder must be in the latched, upper position (*Fig. 128*). Rotate the yoke until the stop post contacts the base of the probe holder (*Fig. 134*). Then tighten the transverse adjustment screw.

5.8.4.4 Probe Holder Longitudinal Adjustment

To adjust the probe holder's vertical angle for longitudinal scanning, follow these steps:




Fig. 135 - Loosen 3 mm screw




Fig. 136 - Rotate to position




Fig. 137 - Line up markers

1. Ensure the probe holder is in the latched upper position (*Fig. 128*).
2. Using the supplied 3 mm hex driver (*Fig. 69*), loosen the longitudinal adjustment screw (*Fig. 135*).
3. Rotate the main body of the probe holder until it is at the desired angle (*Fig. 136*).
4. Tighten the longitudinal adjustment screw (*Fig. 136*).

To return the longitudinal adjustment to neutral (90°). Line up the longitudinal adjustment indicator markers (*Fig. 137*).

5.8.4.5 Probe Holder Left/Right Conversion

To reverse the probe holder, follow these steps:

NOTE: To perform this operation, the 1.5 mm hex wrench (Fig. 72) is required.

1. Ensure the probe holder is in the latched upper position (Fig. 128).




Fig. 138 - Unscrew yoke pivot screw




Fig. 139 - Remove probe holder arms

2. Using the supplied 3 mm hex driver (Fig. 69), unscrew the yoke pivot screw and remove the yoke (Fig. 138).
3. Loosen the probe holder arm adjustment knob and the arm clamp screw. Slide the probe holder arms off the yoke (Fig. 139).




Fig. 140 - Flip yoke and reverse arms




Fig. 141 - Attach arms & move buttons

4. Flip the yoke 180° and reverse the probe holder arms (Fig. 140).
5. Place the pivot buttons on the inside of the probe holder arms (Fig. 141) using a 3/8 in wrench (Fig. 70).




Fig. 142 - Screw yoke to opposite side




Fig. 143 - Lower 90° stop post

6. Mount the yoke to the opposite side of the base using the supplied 3 mm hex driver (Fig. 142).

TIP: Keep the yoke level with the base to ensure no conflicts with the plunger/set screw attached to the yoke.

7. Locate the recessed M3 screw (stop post) on the bottom of the probe holder. Unscrew the stop post using a 1.5 mm hex wrench until it has cleared all obstructions. Do not remove the stop post (Fig. 143).




Fig. 144 - Raise opposite 90° stop post





Fig. 145 - Reversed probe holder

8. Raise the stop post on the opposite side until the side of the post contacts the 90° stop point on the probe holder's base (Fig. 144).

5.8.5. Slip Joint Probe Holder



A	Frame Bar
B	Probe Holder Adjustment Knob
C	Latch
D	Swing Arm Knob
E	Yoke
F	Probe Holder Arm Adjustment Knob
G	Probe Holder Arm
H	Arm Clamp Screw
I	Pivot Buttons

Fig. 146 - Slip Joint Probe Holder

5.8.5.1 Probe Holder Setup

To mount a UT wedge in the probe holder, follow these steps:




Fig. 147 - Attach to frame bar




Fig. 148 - Adjust on frame bar

1. Rotate the probe holder adjustment knob and attach the probe holder to a frame bar (Fig. 147).
2. Use the probe holder adjustment knob to position the probe holder along the frame bar (Fig. 148).




Fig. 149 - Adjust swing arm




Fig. 150 - Place pivot buttons

3. Use the swing arm knob to position the swing arm (Fig. 149).

TIP: The swing arm is typically used to adjust TOFD center to center distance relative to the phased array probes on a four probe configuration.

4. Using the supplied 3/8 in wrench (Fig. 70), place the pivot buttons (Fig. 150) farthest from the yoke for maximum wedge clearance.

TIP: If narrow scanning footprint is required, use pivot button holes closest to the yoke. Wedge pivoting may be impeded when closer to the yoke.




Fig. 151 - Adjust probe holder arms




Fig. 152 - Place wedge

5. Loosen the probe holder arm adjustment knob (Fig. 151) and remove the outer probe holder arm from yoke.
6. Adjust the inner probe holder arm as required to best centre the probe on the yoke's pivot axis (Fig. 151).

TIP: The probe holder yoke can accommodate many different probe and wedge sizes of varying widths. It is best to centre the wedge with the yoke's pivot axis to reduce wedge tipping when scanning. Position the inner probe holder arm accordingly with the centre of the yoke (Fig. 151).

7. Position the wedge on the inner probe holder arm (Fig. 152).
8. Slide the outer probe holder arm along the yoke pinching the wedge in place.
9. Tighten the probe holder arm adjustment knob (Fig. 153).




Fig. 153 - Pinch wedge with arm

5.8.5.2 Probe Holder Adjustment

To adjust the probe holder, follow these steps:




Fig. 154 - Lift to latched position




Fig. 155 - Lower to scanning surface

1. Ensure the probe holder is in the latched upper position (Fig. 154). If the probe holder is already latched, it will only move within the slip joint adjustment range and have no spring tension.
2. Push the probe holder yoke down toward the inspection surface until the wedge is approximately 6 mm ($\frac{1}{4}$ in) from the inspection surface (Fig. 155).




Fig. 156 - Lift and press latch button




Fig. 157 - Spring loaded scan position

3. Lift the probe slightly and press the latch button (Fig. 156) to apply spring pressure to the wedge.
4. Gently lower probe holder and wedge to the scanning surface (Fig. 157).

5.8.5.3 Probe Holder Force Adjustment

It is possible to adjust the tension of the probe holder spring.

NOTE: The 2 mm hex wrench (Fig. 73) and 3 mm hex wrench (Fig. 74) are required to perform this operation.

Light	1 kg	2 lb
Medium	2 kg	4 lb
Heavy	3 kg	6 lb

When configured correctly, these settings exert the indicated spring force on the Probe.

To adjust the probe holder's force, follow these steps:

NOTE: Do not perform this operation on the scanning surface.




Fig. 158 - Lift slightly and press latch




Fig. 159 - Unlatched position

1. Ensure the probe holder is in the upright latched position (Fig. 154).
2. Lift the probe holder slightly and press the latch button (Fig. 158) to release the probe holder to the full 45° degrees.
3. Insert the short arm of a 3 mm hex wrench into the 3 mm slot (Fig. 159).




Fig. 160 - Insert hex tools




Fig. 161 - Press 3 mm hex wrench down

4. Place the 2 mm hex wrench into the force adjustment screw (Fig. 160).
5. Lightly press the long arm of the 3 mm hex wrench down. Using the 2 mm hex wrench, loosen the force adjustment screw but do not remove it (Fig. 161).
6. Gently apply pressure on the long leg of the 3 mm hex wrench until the force adjustment marker lines up with the desired spring tension. While keeping the markers in line, tighten the force adjustment screw (Fig. 162).




Fig. 162 - Choose desired tension

5.8.5.4 Slip Joint Probe Holder Left/Right Conversion

To reverse the probe holder, follow these steps:




Fig. 163 - Unscrew yoke pivot screw




Fig. 164 - Remove arms

1. Unscrew the yoke from the swing arm (Fig. 163).
2. Loosen the probe holder arm adjustment knob and arm clamp screw. Slide the arms from the yoke (Fig. 164).




Fig. 165 - Flip yoke and reverse arms




Fig. 166 - Attach arms and move buttons

3. Flip the yoke 180° and reverse the probe holder arms (Fig. 165).
4. Place the pivot buttons on the inside of the probe holder arms (Fig. 166) using a 3/8 in wrench (Fig. 70). Slide the arms onto the yoke and tighten the probe holder arm adjustment knob and the arm clamp screw.




Fig. 167 - Position swing arm




Fig. 168 - Install yoke to swing arm

5. Loosen the swing arm knob and slide the swing arm to the opposite end of the probe holder bracket (*Fig. 167*) or the preferred position. Tighten the swing arm knob.
6. Using the 3 mm hex driver, screw the yoke pivot screw into the opposite side of the probe holder swing arm (*Fig. 168*). Ensure the yoke is level to avoid issues with the plunger/set screw.




Fig. 169 - Reversed probe holder

5.8.6. Heavy Duty Vertical Probe Holder

- A Latch
- B Probe Holder Arm Adjustment Knob
- C Yoke
- D Probe Holder Arms
- E Pivot Buttons
- F Arm Clamp Screw
- G Probe Holder Adjustment Knob
- H Vertical Adjustment Knob




Fig. 170 - Heavy duty vertical probe holder

5.8.6.1 Probe Holder Setup




Fig. 171 - Mount probe holder to carrier




Fig. 172 - Vertical adjustment

1. Loosen the probe holder adjustment knob (*Fig. 171*) and mount the heavy duty vertical probe holder's dovetail jaw to the carrier.
2. The vertical adjustment knob (*Fig. 172*) allows height adjustment of the heavy duty vertical probe holder. This adjustment also controls the probe holder's spring tension.




Fig. 173 - Remove outer arm




Fig. 174 - Adjust inner arm

3. Loosen the probe holder adjustment knob and remove the outer probe holder arm (Fig. 173).
4. Loosen the arm clamp screw (Fig. 174).
5. Place the wedge on the pivot button of the inner probe holder arm (Fig. 174).




Fig. 175 - Align probe with yoke




Fig. 176 - Tighten knob and screw

6. Align the middle of the wedge with the centre of the yoke (Fig. 175).
7. Tighten both the probe holder adjustment knob and the arm clamp screw (Fig. 175) while ensuring the wedge remains centred with the yoke.

5.8.6.2 Probe Holder Vertical Adjustment




Fig. 177 - Press up and pull latch




Fig. 178 - Lowered toward scan surface

1. Gently lift the heavy duty vertical probe holder and simultaneously pull the latch (Fig. 177). This action will unlock the probe holder. Slowly lower the probe holder towards the scan surface (Fig. 178).

5.8.6.3 Probe Holder Left/Right Conversion




Fig. 179 - Remove yoke




Fig. 180 - Orient to opposite side

1. Using the supplied 3 mm driver, unscrew the yoke (Fig. 179).
2. Position the yoke and arms to the opposite side of the probe holder (Fig. 180).




Fig. 181 - Remove probe holder arms




Fig. 182 - Reverse position around yoke

3. Loosen the arm clamp screw and probe holder arm adjustment knob allowing the removal of the probe holder arms (*Fig. 181*).
4. Position removed arms to opposite sides of the yoke (*Fig. 182*).




Fig. 183 - Position pivot buttons




Fig. 184 - Place arms back onto yoke

5. Position the pivot buttons to the inside of the probe holder arms (Fig. 183).
6. Place the probe holder arms on the yoke and tighten the arm clamp screw and probe holder adjustment knob (Fig. 184).
7. Screw the yoke to the probe holder (Fig. 185).

TIP: Position the yoke in the threaded hole closest to the frame bar when using a standard yoke length. Position the yoke in the threaded hole furthest from the frame bar when using a wide yoke length.




Fig. 185 - Screw into threaded hole

5.8.6.4 Probe Holder 90° Adjustment

1. Remove the yoke using the supplied 3 mm hex driver (Fig. 69).
2. Orient the yoke to the front of the probe holder and screw the yoke into the threaded hole provided (Fig. 186).




Fig. 186 - 90° probe holder positioning

5.9. 3-Axis Nozzle Scanning

Using the right drive module, the **NAVIC** may be configured to perform nozzle scan operations. To set up the scanner, follow these steps:



WARNING! MAGNETIC MATERIAL. The wheels of the crawler produce an extremely strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics. People with pacemakers or ICD's must stay at least 75 cm (30 in) away.



CAUTION! PINCH POINT HAZARD. Keep fingers clear of pinch points when connecting/disconnecting left and right modules.




Fig. 187 - NAVIC nozzle scanning configuration

5.9.1. Scanner Preparation

1. Remove the left drive module from the crawler (see *"Connecting/Disconnecting Left and Right Modules"* on page 67).




Fig. 188 - Mount the umbilical at 90° from standard mounting angle

2. Mount the umbilical at a 90° angle to the right drive module (see “Umbilical” on page 60), tighten the black wing knob (Fig. 188).
3. Plug in the right drive module’s connector to the umbilical (Fig. 188).
4. Mount cable management to the umbilical (see “Mounting Cable Management” on page 122).
5. Mount the probe/wedge (Fig. 190) to the long stroke vertical probe holder (see “Probe Holder Setup” on page 96).




Fig. 189 - Mount cable management to the umbilical




Fig. 190 - Probe/wedge affixed to probe holder




Fig. 191 - Adjust pivot, tapered lock to 90° angle

6. Release the pivot, tapered lock and position the 3-axis nozzle frame 90° (Fig. 191). Tighten the pivot tapered lock.
7. Ensure the swivel mount of the **NAVIC** is horizontally aligned (Fig. 192) with the etched line on the crawler (see "Swivel Mount" on page 59 for additional details).




Fig. 192 - Align swivel mount with etched line




Fig. 193 - Mount the umbilical at 90° from standard mounting angle

8. Loosen the black wing knobs of the **NAVIC** swivel mount (Fig. 193-1).
9. Mount the frame bar of the 3-axis nozzle frame to the right drive module's swivel mount (see "Swivel Mount" on page 59).
10. Tighten the swivel mount's black wing knobs.

NOTE: Reposition the slider pps if the probe holder contacts right drive module.

11. Route the 3-axis encoder cable (Fig. 194) through the cable management (see "Cable Management" on page 122).




Fig. 194 - Route the 3-axis encoder cable through the cable management

12. Using the cable clips, route the encoder cable from the slider pps to the 3-axis encoder cable (Fig. 195).

13. Using the cable clips, route the encoder cable from the probe holder to the 3-axis encoder cable (Fig. 195).

14. Plug the encoder cables into the 3-axis encoder cable connectors (Fig. 195).

15. Plug the opposite end of the 3-axis encoder cable into the power controller's encoder receptacle (Fig. 196).

16. Connect the 3-axis encoder cable to the user's instrument (see "3-Axis Nozzle Scanning" on page 57).




Fig. 195 - Connect encoder cables to 3-axis encoder cable




Fig. 196 - Plug 3-axis encoder cable into the power controller

17. Connect the handheld controller to the power controller using the auxiliary cable (Fig. 197).




Fig. 197 - Connect handheld controller to power controller

5.9.2. 3-Axis Nozzle Operation

NOTE: The encoder cabling removed for illustration purposes.




Fig. 198 - Place scanner on surface using installation/removal mat

1. Place the configured scanner on the inspection surface (see “Scanner Installation/Removal Mat Use” on page 130).




Fig. 199 - Unlatch encoded skew vertical probe holder

2. Unlatch the encoded skew vertical probe holder (see *"Encoded Skew Vertical Probe Holder Adjustment"* on page 98).




Fig. 200 - Drive crawler

3. Using the handheld controller, drive the crawler around the nozzle as required (see *"Jog Mode"* on page 134).




Fig. 201 - Adjust the slider PPS as required

4. Adjust the Slider PPS as required (*Fig. 201*) to position the probes distance from the weld.
5. Ensure the **A** slider lock knob is tight and rotate the main knob to position the slider (*Fig. 202*).




Fig. 202 - Slider positioning

6. Adjust the skew angle of the probe as required (see “Skew Angle Adjustment” on page 100).




Fig. 203 - Adjust skew angle

5.9.3. Encoded Skew Vertical Probe Holder




Fig. 204 - Encoded skew vertical probe holder identification

5.9.4. Probe Holder Setup

1. Using the supplied 3/8 in wrench (Fig. 70), install the appropriate pivot buttons to the probe holder arms (Fig. 205).




Fig. 205 - Attach pivot buttons




Fig. 206 - Mount to slider pps




Fig. 207 - Mount to slider pps

2. Loosen the probe holder adjustment knob to attach the encoded skew vertical probe holder to the slider pps slider (Fig. 206).
3. Loosen the knob to position the probe holder horizontally along the slider pps slider (Fig. 207). Tighten the probe holder adjustment knob when positioning is complete.

To mount a UT wedge in the probe holder, follow these steps:




Fig. 208 - Loosen knobs and move arms




Fig. 209 - Align probe

4. Loosen the two probe holder arm adjustment knobs and move the arms apart to create space for the probe (Fig. 208).
5. Align the probe to be used with the centre of yoke pivot (Fig. 209).

6. Move the probe holder arms and insert the pivot buttons into the probes pivot button holes while maintaining the probes alignment relative to the yoke's pivot (Fig. 210).
7. Tighten the two probe holder arm adjustment knobs (Fig. 210).




Fig. 210 - Clamp probe with arms and tighten knobs

5.9.5. Skew Encoder Cable

The encoder cable of the encoded skew vertical probe holder provides encoded feedback of the probe holder's skew angle. Cable routing is at the discretion of the user. Cable clips have been provided to assist with cable management.

1. Route the skew encoder cable through any required cable clips.
2. Plug the skew encoder cable into the 3-axis encoder cable.

5.9.6. Encoded Skew Vertical Probe Holder Adjustment

To lower the probe (*and probe holder*) to the scan surface, follow these steps:

TIP: The skew encoder cable removed for illustration purposes.




Fig. 211 - Lift probe holder




Fig. 212 - Pull latch pin

1. Lift the probe holder slightly to allow the release of the latch pin (Fig. 211).

2. Pull the latch pin (Fig. 212) and slowly lower the probe holder to the scan surface (Fig. 213).

NOTE: The probe holder must be lifted slightly to pull and release the latch pin.




Fig. 213 - Lower probe to inspection surface

5.9.6.1 Latch Pin

The latch pin may be used in one of two methods:

1. Slightly lift the probe holder (Fig. 211).
2. Pull the latch pin to allow movement of the probe holder (Fig. 214).
3. Release latch pin and probe holder will lock when lifted to the uppermost position.




Fig. 214 - Pull latch pin

Method two allows free movement of the probe holder along the entire length of the stroke without locking in place at the uppermost position:

4. Slightly lift the probe holder (Fig. 211).
5. Pull the latch pin and slightly rotate the latch pin left or right (Fig. 215).
6. Release the latch pin, and probe holder movement is now available through the entire




Fig. 215 - Pull latch pin and rotate

length of the stroke without latching.

7. Rotate the latch pin to return the probe holder to the locking capable position.

5.9.7. Skew Angle Adjustment

Rotation of the probe holder is possible through adjustment of the skew angle.




Fig. 216 - Loosen ratchet lever




Fig. 217 - Adjust skew angle

1. Loosen the ratchet lever above the yoke (Fig. 216).
2. Rotate the yoke (Up to 90° in either direction) to the angle required (Fig. 217).
3. Tighten the ratchet lever to lock the yoke in place. Should the ratchet lever be unable to fully tighten or release the yoke (see *Ratchet Lever* on page 101 for more information).
4. The engraved arrow above the yoke may be used to align the yoke to the required degree.




Fig. 218 - Engraved arrow aligns with various degree measurements

5.9.7.1 Ratchet Lever




Fig. 219 - Pull ratchet handle




Fig. 220 - Rotate handle




Fig. 221 - Tighten handle

The ratchet levers are used for various locking functions on the **NAVIC** system. Occasionally, movement of the lever locking position is required. The lever placement can be adjusted by following these steps:

1. Pull the ratchet lever away from the base to which it is connected (*Fig. 219*).
2. Continue to pull while rotating the lever in the appropriate direction (*Fig. 220*).
3. Release the lever and utilize the new tightening position (*Fig. 221*).

5.9.8. Pivot Buttons

Available in a variety of shapes and sizes, fitting various wedge dimensions.

Use the supplied 3/8 in wrench (*Fig. 70*) to remove and install pivot buttons (*Fig. 222*).




Fig. 222 - Tighten pivot buttons to probe holder arms

5.9.9. Cable Clips

Cable clips have been provided to assist with cable management. Simply pinch the clip and press it into the dovetail groove of the frame bar or the probe holder.




Fig. 223 - Pinch clip




Fig. 224 - Cable clip




Fig. 225 - Route cables

5.10. Slider PPS (*Slider Probe Positioning System*)

The slider PPS uses a slide and leadscrew system to manipulate a probes position along a frame bar. To setup and install a slider PPS follow these steps:




Fig. 226 - Place slider on frame bar and loosen slider lock knob

1. Ease the slider onto the frame bar and push it into position (*Fig. 226*). The slider's friction fit requires an appropriate amount of force to position the slider.
2. Loosen the slider's lock knob (*Fig. 226 - note red highlight*).




Fig. 227 - Place main knob on frame bar

3. Loosen the main knob's hexagonal screw and lock screw (*Fig. 227 - note red highlight*).
4. Align the dovetail nut of the main knob with the frame bar and slide it into position (*Fig. 227*).




Fig. 228 - Insert leadscrew into main knob and slider

5. Rotate the leadscrew to insert it into the main knob and slider (Fig. 228).




Fig. 229 - Tighten screws

6. Position the slider and main knob where required along the frame bar.
7. Tighten the main knob's hexagonal screw and lock screw, as well as tighten the slider lock knob (Fig. 229 - note red highlight).

5.10.1. Slider PPS Encoder

The slider PPS (*probe positioning system*) encoder is used to provide positional feedback perpendicular to the scan direction of travel. Follow these steps for installation:




Fig. 230 - Loosen and slide post in place




Fig. 231 - Align and mount post

1. Ensure the encoder's lock screw is loose.
2. Slide the encoder's dovetail nut onto the frame bar (*Fig. 230*), and continue sliding the encoder towards the leadscrew until the leadscrew is pressed snugly into the encoder's coupling (*Fig. 231*).
3. Tighten the encoder's lock screw (*Fig. 231 - note red highlight*).




Fig. 232 - Route encoder cable to the 3-axis encoder cable

4. Route the PPS encoder cable as required to plug into the 3-axis encoder cable (*Fig. 232*).

5.11. Probe Holder Frames

5.11.1. Vertical Probe Holder Frame - Flat or Circumferential Only



WARNING! FALLING OBJECT HAZARD.

When the Probe Holder Frame is mounted in both the left hand and right hand swivel mounts, operation must be limited to driving in the circumferential direction. Only very slight corrective steering is permitted. Excessive steering may cause the crawler to fall and **SEVERE INJURY** or **DEATH** could result.



WARNING! FALLING OBJECT HAZARD.

It is imperative that the steps below be followed to properly set the height of the probe holder frame. If the height of the probe holder frame is set too low, the crawler may fall and **SEVERE INJURY** or **DEATH** could result.




Fig. 233 - Vertical probe holder frame

The vertical probe holder frame adds weld scanning capability to the **NAVIC** motorized scanner. This frame uses (4) vertical probe holders. Additional frame components allow up to six probes to be used (contact Jireh Industries Ltd. on page 1).

1. Attach the wedges to the probe holders that will be used (see “Probe Holder Setup” on page 69 for additional details).




Fig. 234 - Position primary and secondary probe holders

2. Affix the probe holders (with attached wedges) to the probe holder frame. Place the secondary probe holder at the front of the **1** frame and place the primary probe holders at the rear of the **2** frame bar (Fig. 234).

TIP: Due to their larger size, scan results are generally improved when pulling or dragging phased array wedges.

3. Mount the probe holder frame to the crawler (see “Swivel Mount” on page 64 for additional details). When mounting the probe holder frame, ensure the attachment knobs (Fig. 234) are at the front (non-crawler side).




Fig. 235 - Align swivel mount with scan surface

4. Release the two swivel mount levers (Fig. 235) to position the swivel mount parallel to the scan surface (Fig. 236). When alignment with the scan surface is achieved, lock the crawler swivel mount levers.




Fig. 236 - Set rear rotational adjustment knob

5. Loosen the rear rotational adjustment knob to lower the weld scan frame towards the inspection surface. Ensure gap **B** (Fig. 237) is no smaller than gap **A** (Fig. 236).




Fig. 237 - Set front rotational adjustment knob

6. Loosen the front rotational adjustment knob (Fig. 237) to lower the weld frame towards the inspection surface while ensuring gap **C** (Fig. 238) is no smaller than gap **A** (Fig. 236).




Fig. 238 - Align probes with the scan surface tangent

7. Lower the probe holders to the inspection surface.
(see "Probe Holder Vertical Adjustment" on page 70).

5.11.2. Low Profile Probe Holder Frame - Flat or Circumferential Only



WARNING! FALLING OBJECT HAZARD.

When the Probe Holder Frame is mounted in both the left hand and right hand swivel mounts, operation must be limited to driving in the circumferential direction. Only very slight corrective steering is permitted. Excessive steering may cause the crawler to fall and **SEVERE INJURY** or **DEATH** could result.



WARNING! FALLING OBJECT HAZARD.

It is imperative that the steps below be followed to properly set the height of the probe holder frame. If the height of the probe holder frame is set too low, the crawler may fall and **SEVERE INJURY** or **DEATH** could result.




Fig. 239 - Low profile probe holder frame

The low profile frame adds weld scanning capability to the **NAVIC** motorized scanner. This frame can utilize (4) slip joint probe holders (2 Phased Array and 2 TOFD, typically). The low profile design of this frame allows for scanning on diameters where radial clearance is limited.

1. Attach the wedges to the probe holders that are to be used (see “Probe Holder Setup” on page 69 for additional details).




Fig. 240 - Position primary and secondary probe holders

2. Affix the probe holders (with attached wedges) to the low profile probe holder frame. On the frame bar, place the **2** secondary probe holders at the front and the **1** primary probe holders at the rear (Fig. 240).

TIP: Due to their larger size, scan results are generally improved when pulling or dragging phased array wedges.

3. Mount the low profile probe holder frame to the crawler (see “Swivel Mount” on page 64 for additional details). When mounting the low profile frame, ensure the attachment knobs (Fig. 240) are at the front (non-crawler side).




Fig. 241 - Align swivel mount with scan surface

4. Release the two swivel mount levers (Fig. 241) to position the swivel mount parallel to the scan surface (Fig. 242). When alignment with scan surface is achieved, lock the crawler swivel mount levers.




Fig. 242 - Set rear rotational adjustment knob

5. Loosen the rear rotational adjustment knob to lower the front frame bar of the low profile frame towards the inspection surface (Fig. 242). Ensure gap **B** (Fig. 243) is no smaller than gap **A** (Fig. 242).




Fig. 243 - Align probe holder tangent with scan surface

6. Loosen the front rotational adjustment knob (Fig. 243) to align the frame bar parallel with the scan surface (Fig. 243).




Fig. 244 - Low profile probe holder frame

7. Lower the probe holders to the inspection surface.
(see *"Probe Holder Adjustment"* on page 77).

5.11.3. Pivoting Probe Holder Frame



WARNING! FALLING OBJECT HAZARD.

It is imperative that the steps below be followed to properly set the height of the probe holder frame. If the height of the probe holder frame is set too low, the crawler may fall and **SEVERE INJURY** or **DEATH** could result.

The pivoting probe holder frame utilizes vertical probe holders. The **NAVIC** can guide as many as 6 probes in the longitudinal or circumferential direction.

NOTE: A minimum OD of 305 mm (12 in) is required for longitudinal scanning.




Fig. 245 - Pivoting Probe Holder Frame

5.11.3.1 Mounting a Pivoting Probe Holder Frame



WARNING! FALLING OBJECT HAZARD.

The Pivoting Probe Holder Frame is to be mounted only in the right hand swivel mount. Mounting it in both the left hand and right hand swivel mounts may cause the crawler to fall and **SEVERE INJURY** or **DEATH** could result.

1. Attach the wedges that are to be used with the probe holders (see “Probe Holder Setup” on page 69 for additional details).




Fig. 246 - Connect frame to right drive module

2. Affix the probe holders (*with attached wedges*) to the probe holder frame. Place the secondary probe holders at the front of the **1** frame while placing the primary probe holders at the rear of the **2** frame system (Fig. 246).

TIP: Phased array wedges are designed to be pulled along a scan surface.

3. Mount the pivoting probe holder frame to the crawler (see “Swivel Mount” on page 64 for additional details).

5.11.3.2 Pivoting Probe Holder Frame Setup - Longitudinal Scanning



WARNING! FALLING OBJECT HAZARD.

When scanning in the longitudinal direction with the Pivoting Probe Holder Frame, operation must be limited to driving in the longitudinal direction only. Only very slight corrective steering is permitted. Excessive steering may cause the crawler to fall and **SEVERE INJURY** or **DEATH** could result.

To prepare the pivoting probe holder frame for longitudinal scanning, follow these steps:




Fig. 247 - Loosen pivot wing knobs

NOTE: The swivel mount must be in a horizontal position during longitudinal scanning (see "Swivel Mount" on page 59).

1. Loosen the pivot wing knobs at the centre of the frame system (Fig. 247). Lower the left side of the frame system to align with the tangent of the scan surface. Tighten the pivot wing knobs.




Fig. 248 - Tighten pivot wing knobs

2. Lower the vertical probe holders (see *"Probe Holder Vertical Adjustment"* on page 70).




Fig. 249 - Correct probe holder longitudinal adjustment

3. Ensure probe holder arms are parallel to the scan surface (see *"Probe Holder Longitudinal Adjustment"* on page 72).

5.11.3.3 Pivoting Probe Holder Frame - Circumferential Scanning

(see *"Vertical Probe Holder Frame - Flat or Circumferential Only"* on page 106 for additional details)

5.11.3.4 Pivoting Probe Holder Frame - Flange Scanning

NOTE: The optical guide pivot mount is incompatible with the following configuration.

The pivoting probe holder frame may be configured to allow scanning of flanges and the like. The following steps explain setup of this configuration:




Fig. 250 - Configure assembly and mount to NAVIC

1. Disassemble the pivoting probe holder frame to achieve the setup shown (Fig. 250). Ensure proper placement of the frame bar with attached mounting point in relation to the **NAVIC**.

TIP: When the scanning surface is circumferential, only one frame bar with two probes can be used.




Fig. 251 - Lift frame bar to avoid interference

2. Loosen the pivot wing knob and raise the frame bar to an angle greater than the surface to be scanned (*Fig. 251*). Tighten the pivot wing knob and place crawler on scan surface (see "Placement of Crawler on Inspection Surface" on page 129).




Fig. 252 - Align swivel mount with scan surface

3. Release the front swivel mount adjustment levers to align the swivel mount parallel to the scan surface (*Fig. 252*).




Fig. 253 - Align frame bar with flange scan surface

4. Loosen the pivot wing knob and align the frame bar parallel with the scan surface (*Fig. 253*).

5.11.3.5 Optical Guide Pivot Mount




Fig. 254 - Optical guide pivot mount installation

An optional mounting point for any optical guide is available.

- ▶ (see “Battery Powered Optical Guide” on page 121)
- ▶ (see “Optical Guide” user manual)

To install the pivot mount, see these following instructions:

1. Remove the dovetail bar pivot from one of the sets of **1** frame bars (Fig. 254). The choice of which dovetail bar pivot to remove is at the user’s discretion.
2. Attach the optical guide pivot mount to the **2** frame bars (Fig. 254), tighten the dovetail knobs and the dovetail screws. Ensure a flush alignment of the pivot mount and the frame bars to achieve proper centring of the optical guide pivot mount.
3. To mount an optical guide see the appropriate instructions listed above.

5.12. Accessories

5.12.1. Battery Powered Optical Guide



WARNING! LASER RADIATION. The battery powered optical guide contains a Class 1M laser. Do not view directly with optical instruments.




Fig. 255 - Battery powered optical guide

The battery powered optical guide provides a reference point to align the **NAVIC** to a given path (*i.e. a weld*).

1. Loosen the battery powered optical guide knob (Fig. 256) and mount the optical guide to the frame bar.
2. Tighten the optical guide knob.
3. Adjust the optical guide's friction pivot to direct the laser beam as required (Fig. 257).
4. Loosen the optical guide knob to adjust the side-to-side position as required. Retighten the optical guide knob.
5. The included perpendicular mount allows for alternate mounting positions when required.




Fig. 256 - Mount on frame bar




Fig. 257 - Aim guide




Fig. 258 - Perpendicular mount

NOTE: The battery powered optical guide requires 1 AA battery for operation.

5.12.2. Cable Management

The cable management is offered in a variety of lengths and provides a means of bundling and protecting cables and hoses that connect to the scanner.

5.12.2.1 Mounting Cable Management

To attach the cable management with threaded mount, follow these steps:




Fig. 259 - Align with umbilical




Fig. 260 - Tighten wing knob

1. Align the cable management clamp with the appropriate mounting position on the umbilical (Fig. 259).
2. Tighten the cable management clamp wing knob (Fig. 260).

5.12.2.2 Cable Management Setup




Fig. 261 - Insert cables and hoses




Fig. 262 - Zip to close

1. Open the cable management tube. Begin at the clamp end and start placing the cabling in the tube (Fig. 261).
2. Follow the cable placement zipping the tube closed (Fig. 262).




Fig. 263 - Zip opposite end




Fig. 264 - Flexible routing

3. Once the cable is placed the entire length of tube, bring the zipper from the opposite end to meet at any point in the middle.

When necessary, the two zippers may be opened to allow any cables to be routed out of the tube.

5.12.2.3 Clamp Setup

In the event the tube becomes disconnected from the cable management clamp, follow these instructions to reattach the tube and clamp.

Loosen the clamp screw using the supplied 3 mm hex driver. Slide the clamp around the tube first, and then slide the tube around the outside of the cable management mount (Fig. 265). Align the tube opening and the cable management clamp opening.

Slide the clamp over the tube and cable management mount, pinching the tube in between (Fig. 266).

Tighten the clamp screw (Fig. 267).




Fig. 265 - Slide tube around mount




Fig. 266 - Slide clamp onto mount




Fig. 267 - Tighten clamp screw

5.12.3. NAVIC Backpack

Intended Use

- ▶ The **NAVIC** backpack is intended to mount objects (e.g. preamps, splitters, etc.) that:
- ▶ have a maximum weight of 1.36 kg (3 lb)
- ▶ are attached to the **NAVIC** with a lanyard or probe cables strong enough to prevent the object from falling
- ▶ have smooth edges so as not to cut backpack velcro strap

To install and use the backpack, follow these steps:

NOTE: The backpack is only compatible with **NAVIC** crawlers manufactured after the spring of 2015.




Fig. 268 - Pivot and insert dovetail nut




Fig. 269 - Tighten screws

1. Allow the **NAVIC** crawler to pivot, exposing the inside of the left drive module (Fig. 268).
2. Slide the dovetail nuts of the backpack into the accessory dovetail groove (Fig. 268).
3. Tighten the two backpack screws using the supplied 3 mm hex driver (Fig. 269).
4. Pull the Velcro straps tight around the item on the backpack (Fig. 270).




Fig. 270 - Use velcro straps

5.12.4. Preamp Bracket

Compatible with most standard preamps, use screws or the optional velcro straps to attach a preamp to the preamp bracket.

Intended Use

- ▶ The **NAVIC** preamp bracket is intended to mount objects (*e.g. preamps, splitters, etc.*) that:
- ▶ have a maximum weight of 1.36 kg (3 lb)
- ▶ are attached to the **NAVIC** with a lanyard or probe cables strong enough to prevent the object from falling
- ▶ have smooth edges so as not to cut bracket's velcro strap

5.12.4.1 Mounting Preamp Bracket

The preamp bracket mounts to any dovetail groove.




Fig. 271 - Loosen knob and mount to dovetail groove




Fig. 272 - Tighten knob

1. Loosen the knob and align with the dovetail groove (*Fig. 271*).
2. Tighten the knob to lock the preamp bracket in place (*Fig. 272*).

5.12.4.2 Attaching Preamp with Screws

Use the adjustable screw mounting channel on the bottom of the bracket to attach a preamp (*screws not included*).




Fig. 273 - Attach preamp with screws

5.12.4.3 Attaching Preamp with Velcro Straps

To attach the preamp to the bracket using velcro straps (*sold separately*), follow these steps:




Fig. 274 - Insert velcro straps

1. Slide the velcro strap through the bracket's holes (*Fig. 274*).
2. Centre and place the preamp on the bracket wrapping the velcro around the preamp (*Fig. 275*).
3. Secure the preamp to the bracket attaching each side of the velcro (*Fig. 276*).




Fig. 275 - Place preamp and wrap velcro




Fig. 276 - Velcro wrapped around preamp

OPERATION

6.1. System Startup




Fig. 277 - Insert power source

To activate the system, follow these steps:

1. Insert the power source (Fig. 277) into the power controller dock.
2. Connect the components (see "NAVIC Configurations" on page 45).




Fig. 278 - Power controller

3. Locate the **2** red stop push-button on the power controller. Rotate this button clockwise to unlatch (Fig. 278).
4. The **1** power button (Fig. 278) on the power controller activates the system.

NOTE: If the crawler is moving due to an external force when power is applied, the system will display a “Please Wait – Motor Moving” message until the movement stops. The crawler must be stationary for system initialization to be performed.




Fig. 279 - Handheld controller

5. A warning message will display on the handheld controller when power has been activated. Once the dangers of using the **NAVIC** are recognized and understood by reading this user manual, touch **Ok** to acknowledge the warning (Fig. 279).




Fig. 280 - Falling object warning

6. A second warning message (Fig. 280) will display requesting assurance that a no-entry fall zone has been established (see “Preparation for Safe Use” on page 38) and tether requirements are met (see “Tether Requirements and Attachment” on page 39). Acknowledge this warning by touching **Yes**.

Once the system is initialized, the **Mode Select** screen will appear (see “Mode Select Screen” on page 134). The system is now ready for operation.

6.2. Placement of Crawler on Inspection Surface



WARNING! FALLING OBJECT HAZARD.

Read and understand the proper procedure for using the Installation/Removal Mat. If crawler installation is done at elevated heights, improper use may cause the crawler to fall and **SEVERE INJURY** or **DEATH** could result.



CAUTION! Do **NOT** handle crawler using the umbilical cable. Use the provided handles.



CAUTION! Do not place the crawler directly on the inspection surface. Use of the scanner installation/removal mat as a spacer between the wheels and the inspection surface is required during scanner placement. This is necessary to protect the electronic components within the crawler from damaging shock, should the crawler be slammed directly onto the inspection surface.



WARNING! MAGNETIC MATERIAL. The wheels of the crawler produce an extremely strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics.



Tools, magnets and metal objects can cut, pinch or entrap hands and fingers. **HANDLE WITH CARE.**

People with pacemakers or ICD's must stay at least 75 cm (30 in) away.

WARNING! MAGNETIC MATERIAL. The installation/removal mat contains magnetic material. Those with pacemakers or ICD's must stay at least 10 cm (4 in) away.

6.2.1. Scanner Installation/Removal Mat Use

To place the crawler on the inspection surface using a scanner installation mat, follow these steps:

NOTE: For scanner installation/removal on inspection surfaces with a temperature between 50°C and 150°C (122°C and 302°C), use the medium temperature installation/removal mat found in the automated crawler medium temperature add-on kit. Also, ensure the medium temperature cable management is used in place of cable management (see “Cable Management” on page 122)

NOTE: The manufacturer recommends two persons install the crawler on an inspection surface when using the scanner installation/removal mat.




Fig. 281 - Front swivel adjustment levers

Once crawler preparation is complete (see “Preparation for Use” on page 38).

Raise the front swivel mounts (see “Swivel Mount” on page 59) and umbilical mount (see “Umbilical” on page 60) to ensure they will not hinder the wheels from contacting the inspection surface (Fig. 283).




Fig. 282 - Proper swivel mount position




Fig. 283 - Incorrect swivel mount position

1. Set the crawler to Jog Mode (see “Jog Mode” on page 134).




Fig. 284 - Place installation/removal mat




Fig. 285 - Lower crawler to mat

2. Place the installation/removal mat (Fig. 284) on the inspection surface (Fig. 284).
3. Place and hold the crawler on the installation/removal mat (Fig. 285).




Fig. 286 - Drive crawler off the mat




Fig. 287 - Magnetized to surface

NOTE: Do **NOT** let go of the crawler until instructed to do so below.

4. Ensure all four wheels of the crawler are held firmly against the installation/removal mat. While holding the crawler, use **Jog Mode** (see “Jog Mode” on page 134) to carefully drive (Fig. 286) the crawler off the installation/removal mat and onto the inspection surface (Fig. 287).
5. Once the crawler is securely on the inspection surface, the user may let go of the crawler (Fig. 287).

TIP: Avoid the drive modules slamming onto the inspection surface. This can occur when all four wheels are not in contact with the installation/removal mat while the crawler is driven onto the inspection surface.

6. Remove the installation/removal mat from the inspection surface.

TIP: Circumstance may arise when only one person is available for placement of the crawler on an inspection surface. With the system power off, it is possible to place the crawler on the inspection/removal mat and manually push the crawler off the mat and onto the inspection surface.

7. Align front swivel mounts and umbilical mount to appropriate relationship to the scan surface (Fig. 288).




Fig. 288 - Align swivel mounts parallel to scan surface

6.3. Operation

6.3.1. Handheld Controller Layout




Fig. 289 - Handheld Controller

1	Fwd/Rev joystick	(see "Joysticks" on page 133)
2	Touchscreen	(see "Touchscreen" on page 133)
3	Steering/Raster joystick	(see "Joysticks" on page 133)
4	Controller cable connector	Connection point for the auxiliary cable.
5	D-pad	A means of navigating the on-screen menus of the handheld controller.

6.3.1.1 Touchscreen

The **2** handheld controller's touchscreen is the primary operator interface for the system (*Fig. 289*). Buttons are indicated on-screen with a red border.

6.3.1.2 D-pad

The **5** D-pad (*Fig. 289*) provides a redundant system control that may be utilized as an alternative to the touchscreen. A blinking box around a button indicates the D-pad selection. Pressing the outer buttons of the D-pad selects different buttons on-screen. Press the centre button of the D-pad to choose the button currently selected.

6.3.1.3 Joysticks




Fig. 290 - Handheld controller joysticks

The joysticks control system motion. The **L** left joystick controls the forward/reverse movement of the crawler. The **R** right joystick function is selected on screen. Functions include crawler steering or motorized raster arm movement (*Fig. 290*).

6.3.2. Mode Select Screen




Fig. 291 - Mode select

The **Mode Select** screen offers four modes of operation for the system:

Jog Mode	(see “Jog Mode” on page 134)
Latched Jog Mode	(see “Latched Jog Mode” on page 136)
1 Axis Scan Mode	(see “1 Axis Scan Mode” on page 137)
System Utilities	(see “System Utilities Screen” on page 140)

6.3.3. Jog Mode




Fig. 292 - Button identification

Jog mode manually controls the system movement using the joysticks.

- 1** Scan/Rapid Button
(Fig. 292)

Used to quickly switch between crawler speeds. The speed in either mode can be manually set to the user's preference. Rapid mode also changes the steering sensitivity according to the user settings.

TIP: Fine adjustments to speed and steering can be made in the User Settings (see “User Settings Screen” on page 141).

2 Zero Button

Sets the current position to zero for all modules.

3 Module Position Button(s)

Displays the current position of the crawler. Press to set the position to any value using the **Edit** screen. When a module position is modified, the position will be modified for all other system modes. When the right crawler module is connected, the crawler position displayed refers to the position of the auxiliary idler encoder, which is located between the module's wheels.

NOTE: This function only zeroes the number displayed on the **NAVIC** handheld controller. It does not zero the position used in the data acquisition instrument.

4 Module Rate Button(s)

Displays the current maximum rate for the selected speed mode. Press to set the maximum rate using the **Edit** screen. The movement commanded by the joysticks will be limited to the indicated rate. When a rate is modified, the rate will be modified for all other system modes.

5 Exit Button

Exits the jog mode and returns to the **Mode Select** screen.

6 BiasOn/BiasOff button
(Fig. 293)

When the Steering Bias setting is non-zero, a button is displayed to allow steering bias for the right steering joystick to be turned on and off. (see "User Settings Screen" on page 141)




Fig. 293 - BiasOn/BiasOff button identification

6.3.4. Latched Jog Mode




Fig. 294 - Latched jog mode




Fig. 295 - Latched jog stop screen

Identical to standard jog mode, latched jog mode adds forward or reverse crawler movement at the selected scan rate. This eliminates the need to manually hold the left joystick (see “Jog Mode” on page 134).

7 FWD & REV Buttons:

The **FWD** and **REV** buttons are located in the crawler tab. Press the **FWD** or **REV** button to drive the crawler at the current maximum scan rate. When the crawler is in motion, the steering joystick is still enabled. Touching the handheld controller screen or pressing the D-pad stops crawler movement.

NOTE: The FWD & REV Buttons will not be present in rapid mode.

6.3.5. 1 Axis Scan Mode




Fig. 296 - 1 Axis scan mode

1 Axis Scan mode drives the crawler in a straight line, stopping at programmed intervals.

1	Point A	The current encoder position of the crawler.
2	Speed Button	Access the User Settings screen to set the crawler's scan speed.
3	Zero Button	Set the numerical value for rows A and B to zero.
4	Point B	The start point of the scan travel. The system will move the scanner from the A point to this point at the start of a scan.
5	Run Button	Enables the 1 Axis Scan screen (see "1 Axis Scan Screen" on page 138).
6	Point C	The finish point of the overall scan travel.
7	Setting D	The distance the system will advance.

The **1 Axis Scan Setup** screen indicates the scan functions that may be entered. Each point and setting, **A**, **B**, **C**, **D**, corresponds to a coordinate entry button on the screen.

A typical scan begins at the **A** position and moves to the **B** position. Scanning begins at the **B** position and scans the distance of **D** until the **C** position is reached.

6.3.5.1 1 Axis Scan Screen




Fig. 297 - 1 Axis scan screen

The **1 Axis Scan** screen initiates and monitors the scan and advances the set distance. The initial scan screen is an approximation of a full view (*zoomed out*) of the entire scan path.

1	Crawler (Motor) (Fig. 297)	The current encoder position of the crawler. If an idler encoder is available, it will also indicate the encoder selected (<i>Motor or Idler</i>) for crawler positioning as set in the User Settings (see “User Settings Screen” on page 141).
2	Idler Encoder	If an idler encoder is available, the position of the secondary encoder (<i>Motor or Idler</i>) is displayed for reference. This encoder is not used for positioning as per the User Settings (see “User Settings Screen” on page 141).
3	Start/Stop button	Start or stop the scan sequence. When a scan has been stopped while in progress, the start button resumes the scan.
4	Reset	Return the scanner to the A position. Press the start button to begin the scan sequence from the initial setting.
5	Scan location	Small red circle indicates the A position.
6	Scanner position	The blinking crosshair indicates the current scanner position.
7	Next scanner position	Where the scanner will travel to next.

NOTE: The red indicator is always where the scanner will go next.

- | | |
|-----------------------------------------------|------------------------------------------------------------------------------------------------------|
| <p>8 Summary screen</p> <p>9 End position</p> | <p>A visual representation of the scan area.</p> <p>The completed distance of programmed travel.</p> |
|-----------------------------------------------|------------------------------------------------------------------------------------------------------|

When Start is pressed the first time, the scanner will travel to point **B** and pause. The summary screen will show a closer view (*zoom in*) of the scan path.




Fig. 298 - 1 Axis scan screen

- | | |
|--------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>10 Scanner location</p> <p>11 Exit button</p> | <p>The current encoder position of the crawler.</p> <p>Pressing Exit stops all scanning motion. When the scanner is not in the A position, a warning appears (<i>Fig. 299</i>). The warning alerts that the A position of the scanner will be changed to the current position.</p> |
|--------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|




Fig. 299 - Exit warning

Press **Back** to return to the **1 Axis Scan** screen to reset the scanner and maintain original **A** position. Press **Continue** to exit to **1 Axis Scan Setup** screen.

- | | |
|----------------------------|---------------------------------------------------------------|
| <p>12 Scanner position</p> | <p>The blinking crosshair indicates the scanner position.</p> |
|----------------------------|---------------------------------------------------------------|

- 13 Next scanner position Where the scanner will travel to next.

NOTE: The red indicator is always where the scanner will go next.

- 14 End point Arrow indicates travel will continue to advance. A straight line indicates the end of programmed travel.

6.3.6. System Utilities Screen




Fig. 300 - Utilities screen

The **Utilities** screen provides access to the setup, diagnostics and user preference settings.

User Settings Button (Fig. 300)	Access the User Settings screen allowing for various user preferences to be adjusted.
Diagnostics Button	Enters the Diagnostic screens to monitor system components and function.
Touch Cal Button	Used to initiate the Touch Calibration screen.
Joystick Cal Button	Used to enter the Joystick Calibration screen.
Draw Button	Enters mode used to test the touch screen accuracy and response.

6.3.6.1 User Settings Screen




Fig. 301 - User settings screen

Allows a user to customize the system to their preferences.

The blinking highlighted box indicates the current selection. Use the D-pad or **Up** and **Down** buttons to select different settings.

Press **Edit** to enter the **Edit** screen to apply changes to the selected setting.

The **Exit** button directs to the **System Utilities** screen.

Title	Description	Valid Range	Default
Units	Change the measurement units for display and user entry. When set to 0, units measure in inches. When set to 1, units measure in millimetres.	inches or mm	mm
Scan Steering	Sets the steering limit maximum when using the jog mode scan setting. Lower values make the steering joystick less sensitive and more accurate, enabling better control following a guide or feature. Units are a percentage of the maximum system allowed.	0-100	100%
Rapid Steering	Sets the steering limit maximum when using the Rapid setting within Jog mode. Recommended to be left at 100 to allow maximum crawler maneuverability.	0-100	100%
Crawler Scan	Sets the crawler scan rate in the current units/second. This setting can also be changed through the Jog or Two Axis Scan Speed screens.	0-254 mm/s (0-10 in/s)	76 mm/s (3.0 in/s)
Crawler Rapid	Sets the crawler rapid rate in the current units/second. This setting can also be changed through the Jog screen.	0-254 mm/s (0-10 in/s)	254 mm/s (10 in/s)

Steering Bias	Sets a steering bias for the steering joystick, which may be turned on and off in jog mode. Setting this setting to anything other than 0 will show the bias button on the Jog screen. Steering bias allows the operator to set a fixed steering value when the steering joystick is in its neutral position.	0	-30 to +30%
Display Brightness	Sets the brightness of the display.	0-100	100%
Scan by Idler Wheel	Enables the idler encoder for crawler positioning in 1 and 2 axis scan modes. In automatic scan modes, if an idler encoder is available, enabling it will reduce the actual crawler position error as the idler encoder is not affected by drive wheel slippage on the surface.	Disabled or Enabled	Enabled

6.3.6.2 Diagnostics Screens

Several diagnostic screens allow various system functions to be monitored. Navigate to different diagnostic screens using the **PREV** and **NEXT** buttons. The **Exit** button returns to the **System Utilities** screen.

NOTE: The diagnostic information requires an in-depth understanding of the underlying technologies and programming in the system. Not all functions and information is explained in this manual.

6.3.6.2.1 Detected Modules




Fig. 302 - Detected modules screen

The screen indicates the system software version and displays which modules were detected when the system was activated.

6.3.6.2.2 System 1




Fig. 303 - Diagnostic screen

System 1 diagnostic screen displays general system function information.

PowerOnTime	The total accumulative time the handheld controller has been powered.
Joysticks	Indicates the raw position reading from the joysticks.
TouchScreen	Indicates the raw position reading from the last touchscreen contact.

6.3.6.2.3 System 2




Fig. 304 - Diagnostic screen

Additional general system function information is displayed within the **System 2** screen. An empty button is provided to allow testing of the D-pad.

Free Timer	Value from a free running system timer. If this timer is static, an internal controller issue is present.
Button State	Shows the state of the push-buttons in the D-pad.
Button Timer	Shows the timer associated with the D-pad.

6.3.6.2.4 System 3




Fig. 305 - Diagnostic screen

The **System 3 Diagnostic** screen displays additional system information. The information provided does not typically assist the user.

6.3.6.2.5 LeftDrv, Right Drv,




Fig. 306 - Diagnostic screen

The **LeftDrv**, **Right Drv** screens provide information regarding the status of each motorized module. A screen is available for these components if they are detected upon startup.

Current mA	Displays the output of the module to the motor. The current (<i>mA</i>) displayed is directly proportional to the motor's output torque. This reading can be used to check if the control system is responding to forces on the modules motor.
Temperature	Internal temperature reading of the module in degrees Celsius.




Fig. 307 - Diagnostic screen

AuxEncPos

Displays the position of the auxiliary encoder in counts when connected to the module. When the auxiliary encoder is moved, this number will change. When the encoder is moved from its current position and then back to that exact same position, this number will also return to its original position.

EncPos

The position of the module's motor encoder in counts.

6.3.6.3 Touch Calibration Screen



Fig. 308 - Touch calibration screen

This option allows calibration of the touch screen. Typically, this should not be necessary.

Touch the screen as the markers appear in the four corners of the screen.

TIP: *It is recommended that the markers be touched with a small object to enhance the touch position accuracy during calibration.*

The new calibration is stored immediately when the fourth marker is pressed. The calibration utility exits and return to the **System Utilities** screen. To abort the calibration, the system power may be turned off before the last marker is pressed.

6.3.6.4 Joystick Calibration Screen




Fig. 309 - Joystick error

Typically joystick calibration is only necessary when an off-centre joystick error is detected upon startup (*Fig. 309*). Calibration may also be used when a joystick function does not appear to be properly centred.




Fig. 310 - Joystick calibration screen

Current readings of the joysticks are displayed on the **Joystick Calibration** screen (*Fig. 310*). When the numbers are not near zero, press the **Calibrate** button to recalibrate to 0. The new calibration is stored when the **Exit** button is pressed.

6.3.6.5 Draw



Fig. 311 - Draw utility

The draw utility may be used to test the function of the touchscreen. Exit the utility by pressing the D-pad.

6.3.7. High Internal Temperature Screen



CAUTION! HOT SURFACE. The handles of the crawler and crawler body may be hot to the touch. Use appropriate protective equipment when removing a crawler from a high temperature surface.




Fig. 312 - High internal temperature screen

When the system approaches its maximum operating temperature, the high internal temperature screen will display. When this alert screen is displayed, all motor and system functions will cease.

Press **OK** to reactivate the system to remove **NAVIC** from the scan surface.




Fig. 313 - High internal temperature screen

Should the user choose to continue operating the crawler, the HIGH TEMPERATURE warning will continue to display until the temperature falls below the set temperature limit.

MAINTENANCE

7.1. Safety Precautions Before Maintenance



WARNING! ELECTRICAL SHOCK

HAZARD. Disconnect the power controller when servicing the equipment. The power controller is powered even when the push-button is latched in the off position.



WARNING! MAGNETIC MATERIAL.

The wheels of the crawler produce an extremely strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics.



Tools, magnets and metal objects can cut, pinch or entrap hands and fingers. **HANDLE WITH CARE.**

Those with pacemakers or ICD's must stay at least 75 cm (30 in) away at all times.

7.2. Cleaning

General cleaning of components is important to keep your system working well. All components that have no wiring or cables are completely waterproof. Components can be washed with warm water, dish soap and a medium bristle brush.

Before using the scanner, ensure all connectors are free of water and moisture.

NOTE: All components with wiring, cables or electrical connections are splashproof. However, these components are **NOT** submersible.

NOTE: Never use strong solvents or abrasive materials to clean your scanner components.

7.3. Maintenance Schedule

The **NAVIC** system must be maintained according to the following schedule:

Task	Frequency
<u>Inspect safety apparatus</u> This includes: <ul style="list-style-type: none">• All components of the tether system. Replace damaged components as necessary.• Lifting sling on crawler. If the lifting sling shows signs of damage (<i>e.g. cuts, abrasion, etc.</i>), do NOT use.	Every Use
<u>Clean the drive wheels</u> Debris will collect on the magnetic wheels. Remove this debris before every use. An effective cleaning method uses adhesive backed tape (<i>e.g. duct tape</i>) to 'pull' the debris off the wheels.	Every Use
<u>Inspect cables and connectors</u> Inspect the umbilical cable, the power controller cable and the power cable for damage. Have any damaged cable repaired by a qualified person or replace the cable assembly as necessary. Inspect all connectors for damage or moisture. Straighten bent pins. Dry connectors before using.	Every Use
<u>General cleaning</u> Ensure that the scanner stays relatively clean by wiping off any excess dirt or other contaminants after every use. (<i>see "Cleaning" on page 149</i>).	Every Use

TROUBLESHOOTING

8.1. Startup Issues

Two messages are possible in the event of a startup issue: **Joystick Off Center** or **Checking Network**.

8.1.1. Joystick Off Center




Fig. 314 - Joystick off centre screen

Upon system startup, the joystick positions are detected. When a joystick is detected outside the centre position, the **Joystick Off Center** screen displays, indicating the joystick will be disabled. Press **Ok** to continue system startup. All system functions will work normally with the exception of movements that require joystick operation.

Ensure the handheld controller's joysticks are free of interference and reset the system power to enable joystick control.

If no interference of the joystick is present, the joystick calibration may need to be performed (see "Joystick Calibration Screen" on page 146)

8.1.2. Checking Network




Fig. 315 - Checking network screen

During startup, the system initializes the communications to all the devices on

the network. If the network communication fails for any reason, the **Checking Network** message will appear and remain on screen.

Likely causes of this failure:

1. No devices connected to the network.
2. A problem with one of the devices.
3. Cable issue causing the entire network to fail.

Check the connections of the devices or try removing one device at a time from the system to isolate the problem device.

NOTE: Always turn off the system power before connecting or disconnecting any devices.

8.2. Startup Override




Fig. 316 - Startup override screen

A system maintenance mode may be accessed to correct system issues. Enter the maintenance mode by pressing the handheld controller D-pad while system power is activated. Continue pressing the handheld controller D-pad until the **Startup Override** screen appears.

8.2.1. Scan Devices




Fig. 317 - Searching System screen

This utility scans the system network for devices. All possible device addresses and speeds are scanned. As devices are found, the address of the devices is displayed. When the scanning is complete, power to the system must be cycled.




Fig. 318 - Cycle power screen

When a device is connected to the system but is not detected, this most likely indicates an internal device problem. Plug the suspect device into a different umbilical port and perform the scan again to confirm the device is faulty.

8.2.2. Reset Parameters

If the system parameters become corrupt or a change is made that prevents the system from functioning properly. All system parameters may be restored to their factory settings by selecting this option. When pressing the **Reset Params** button, the changes occur immediately. Power will need to be cycled for the reset to be complete.




Fig. 319 - Cycle power screen

8.2.3. System Parameters

System parameters are factory set to control a variety of functions. These parameters can not be modified. However, special circumstances may occur when modification of these parameters could be recommended by the manufacturer.

Instructions for making changes to the system parameters will only be provided when deemed necessary by the manufacturer.

8.2.4. Device Address

Each device type in the system is factory assigned a unique identifier. This option allows for these identifiers to be changed in the field. Instructions for making changes to the identifiers will only be provided when deemed necessary by the manufacturer.

8.3. Encoder Failure

In the event of an encoder failure, the left drive module's motor encoder may be used to output encoder signals to an instrument.

NOTE: When using the motor encoder to track position, steering may cause wheel slippage, which will affect encoder accuracy.




Fig. 320 - Left drive module encoder connection

To output the motor encoder's signal:

1. Ensure power to the system has been turned off.
2. Plug the **L** left drive module's connector into the umbilical's **1** **X-ENC** socket (Fig. 320).
3. Plug the **R** right drive module's connector into the remaining **2** socket (Fig. 320).
4. Disable the Scan by Idler Wheel setting (see "User Settings Screen" on page 141).
5. Ensure the instrument receiving encoder signals is programmed with the motor encoder's resolution (see "Performance Specifications" on page 8 for additional details).

NOTE: On the Jog screen, the encoder will still be showing the failed idler encoder reading but the instrument will be receiving the left motor's encoder reading and the instrument's position displays can be used to position the crawler.

8.4. Umbilical Troubleshooting

Troubleshooting by way of simple continuity checks through the umbilical is not effective due to the isolation circuit.

Static, spike and signal conditioning are built into the umbilical for the network signals. Power fuses are provided within the umbilical for the power distribution to the various receptacles. When troubleshooting, if a module is not functioning properly when plugged into a receptacle, it may be plugged into any other matching receptacle.

8.5. Additional Issues

Problem	Possible Cause	Solution
Handheld controller display does not activate	Input power requirements not met.	Ensure input power meets requirements. (see “Power Requirements” on page 8)
	Handheld controller not plugged into umbilical	Plug handheld controller into umbilical. Ensure connectors are dry, clean and connector pins are not bent.
	Umbilical cable not properly connected.	Check umbilical cable connections at both ends. Ensure connectors are dry, clean and connector pins are not bent.
	NAVIC system not started.	Start the NAVIC system. (see “System Startup” on page 127)
	Damaged components in handheld controller, crawler, power controller or cabling.	Contact manufacturer. (see “Jireh Industries Ltd.” on page 1)
Handheld controller display is activated, yet crawler does not drive	Handheld controller is not in correct mode for driving.	(see “Mode Select Screen” on page 134 for additional details).
	Damaged components in handheld controller, crawler, power controller or cabling.	Contact manufacturer. (see “Jireh Industries Ltd.” on page 1)
Crawler does not drive and is unreachable	See possible causes for problem one.	See solutions for problem one. If the crawler is still unresponsive (see “Retrieval of a Stranded Crawler” on page 157)
Crawler does not steer properly	A drive module is dead	Contact manufacturer. (see “Jireh Industries Ltd.” on page 1)

All four wheels do not remain on the inspection surface.	Inspection surface is interfering with underside of the drive module housing(s) due to excessive steering on curved inspection surfaces with OD less than 2.1 m (84 in).	Do not steer crawler so severely. Do not use the crawler outside of its intended use (see “Intended Use” on page 3).
System is displaying “Please Wait – Motor Moving” when power is applied.	Crawler is moving when power is applied due to an external force (<i>gravity, etc.</i>).	Manually stop the crawler movement. The crawler must be stationary for system initialization to be performed.

8.6. Retrieval of a Stranded Crawler



WARNING! FALLING OBJECT HAZARD.

The tether system must remain active while retrieving the crawler (*i.e. a mechanism or person must be continuously taking up the slack in the tether*).

Should the **NAVIC** crawler become inoperative while out of reach first attempt, the solutions offered in this manual (see “Troubleshooting” on page 151)

If troubleshooting does not rectify the issue, it may be necessary to retrieve the crawler manually. To do so:

1. Press the stop push-button. This will turn the crawler power off.

NOTE: Under normal conditions, the crawler should begin descending slowly.

2. If the crawler stops descending due to some kind of impediment, use a ladder, man lift or scaffolding to retrieve the crawler.

NOTE: FALLING OBJECT HAZARD. It is **CRUCIAL** that the tether system remains active while retrieving the crawler (*i.e. a mechanism or person must be continuously taking up slack in the tether*).

8.7. Technical Support

For technical support, contact Jireh Industries (see “Jireh Industries Ltd.” on page 1).

SERVICE AND REPAIR



WARNING! ELECTRICAL SHOCK

HAZARD. Disconnect the power controller when servicing the equipment. The power controller is powered even when the stop push-button is latched in the off position.



WARNING! MAGNETIC MATERIAL.

The wheels of the crawler produce an extremely strong magnetic field which may cause failure or permanent damage to items such as watches, memory devices, CRT monitors, medical devices or other electronics.



Tools, magnets and metal objects can cut, pinch or entrap hands and fingers. **HANDLE WITH CARE.**

Those with pacemakers or ICD's must stay at least 75 cm (30 in) away at all times.



WARNING! DO NOT DISASSEMBLE.

No user-serviceable parts. Disassembling any of the components in this product, beyond the instructions in this user manual, could void the regulatory certifications and/or effect the safety of the product.

SPARE PARTS

To order accessories or replacement parts for your **NAVIC** system.
(contact Jireh Industries Ltd. on page 1)

NOTE: These drawings are for parts order. This is not a list of kit contents.

10.1. Crawler




Fig. 321 - Crawler parts

BOM ID	Part #	Description
1	CX0061	Handle

10.2. Kit Components




Fig. 322 - Kit components

BOM ID	Part #	Description
1	AAS061	Installation/removal mat
2	EA470	10 mm (3/8 in) wrench
3	EA480	3 mm (0.118 in) flat driver
4	EA414	3 mm (0.118 in) hex driver
5	UMA017-06	Auxiliary cable
6	UMA030-	Umbilical (various lengths available)
7	CXA009	Lifting sling
8	JP069	Plug: Lemo Receptacle, 10 mm
9	JP070	Plug: Lemo Receptacle, 12 mm
10	CX0174	Plug
11	CXS066	Cap: NAVIC hinge cover
12	CMG009-	Irrigation kit, 2-4 probe, large tube (various lengths available)
13	UMA025-	J300 Encoder cable (see Encoder Connector Type)




Fig. 323 - Kit components

BOM ID	Part #	Description
1	CXA040	Power controller (<i>see Power Cord Type</i>)
2	DY0011	Rubber bumper
3	MD072-008	BHCS, M3x0.5 X 8mm, SST
4	CXS122	Power supply
5	DM0067-L	Handheld controller bumper (<i>left</i>)
6	DM0067-R	Handheld controller bumper (<i>right</i>)
7	DMS005	Handheld controller magnet holder
8	MD049-006	SHCS, M3x0.5 X 6mm, SST
9	DMA006	Handheld controller




10.2.1. Encoder Connector Type

Connector Type	Company/Instrument	Connector Type	Company/Instrument
B	Olympus OmniScan MX Zetec Topaz	G	Sonotron Isonic 25xx
C	Olympus Focus LT Zetec Z-Scan Eddyfi Ectane 2	U	Sonatest Veo / Prisma
E	Olympus OmniScan SX/MX2/X3 M2M MANTIS/GEKKO LEMO	V	Pragma PAUT
F	TD (<i>Technology Design</i>)	AD	Sonatest Veo / Prisma - Single Axis

NOTE: Additional encoder connector types are available.
(contact Jireh Industries Ltd. on page 1)

10.2.2. Power Cord Type

Connector Type	Part #	Power Cord
N	SL032	North American
E	SL039	European
U	SL059	United Kingdom
Z		No Cord



10.3. Cable Management








Fig. 324 - Cable management parts

BOM ID	Part #	Description
1	CXS046-X	Cable Management, Threaded Mount (see <i>Cable Management Sleeving, Length</i>)
2		see <i>Cable Management Sleeving</i>
3	CES066	Cable management clamp
4	CXS073	Cable management mount, threaded mount

10.3.1. Cable Management Sleeving

Length	Part #	Description	
04.5	CX0141	4.5 m (14.8 ft)	
09.5	CX0145	9.5 m (31.2 ft)	
14.5	CX0146	14.5 m (47.6 ft)	
29.5	CX0147	29.5 m (96.8 ft)	

10.4. Probe Holder Frame




Fig. 325 - Probe holder frame parts

BOM ID	Part #	Description
1	CXS043	Vertical probe holder side arm, left
2	CX0125	Knob, M4 x 16 mm
3	CX0126	Knurled Knob, M4 x 0.7 x 11.5 mm, 3 mm hex, 4 mm stand off, SST
4	CXS072-L	Arm mount block, left
5	BG0038-	Frame bar (see <i>Frame Bar</i>)
6	CXS072-R	Arm mount block, right
7	CXS042	Vertical probe holder side arm, right

10.5. Low Profile Probe Holder Frame





Fig. 326 - Low profile probe holder frame parts

BOM ID	Part #	Description
1	CXS023	Low profile side arm
2	CX0125	Knob, M4 x 16 mm
3	CXS072-L	Arm mount block, left
4	CX0126	Knurled knob, M4 x 0.7 x 11.5 mm, 3 mm hex, 4 mm stand off, SST
5	BG0038-	Frame bar (see <i>Frame Bar</i>)
6	CXS072-R	Arm mount block, right


10.6. Pivoting Probe Holder Frame



BOM ID	Part #	Description
1	CXS043	Vertical Probe Holder Side Arm, Left
2	CX0125	Knob, M4 x 16 mm
3	CX0126	Knurled Knob, M4 x 0.7 x 11.5 mm, 3 mm hex, 4 mm stand off, SST
4	CXS072-L	Arm Mount Block, Left
5	BG0038-X	Frame Bar (<i>see Frame Bar</i>)
6	CXS064	NAVIC Front Spacer Mount
7	CXS055	Frame Bar Pivot
8	CXS059	Optical Guide Pivot Mount
9	CXS072-R	Arm Mount Block, Right
10	CXS042	Vertical Probe Holder Side Arm, Right

Fig. 327 - Pivoting probe holder parts


10.7. Slip Joint Probe Holder Parts



BOM ID	Part #	Description
1	PH0104	Knurled Knob, M4 x 0.7 x 18 mm, 4 mm stand off, SST
2	PH0082	Knurled Knob, M4 x 0.7 x 10 mm, 3 mm stand off, SST
3	PHS022	Slip Joint Probe Holder Subassembly
4	see <i>Swing Arm Style</i>	
5	MD050-010	SHCS, M4 x 0.7 x 10 mm, SST
6	see <i>Yoke Style</i>	
7	see <i>Arm Style</i>	
8	PH0011-X	Pivot Button Style (see <i>Pivot Button Style</i>)

Fig. 328 - Slip joint probe holder parts


10.8. Vertical Probe Holder Parts



BOM ID	Part #	Description
1	PHS028	Vertical Probe Holder Subassembly
2	MA307	Screw, M4x16 mm High Strength SST SHCS
3	PH0087	Vertical Probe Holder Base
4	MD050-016	SHCS, M4 x 0.7 x 16 mm, SST
5	MA096	Screw, M3x8 mm Dog Point Set, SST
6	MD050-010	SHCS, M4 x 0.7 x 10 mm, SST
7	PH0082	Knurled Knob, M4 x 0.7 x 10 mm, 3 mm stand off, SST
8	see Yoke Style	
9	see Arm Style	
10	PH0011-X	Pivot Button Style (see Pivot Button Style)

Fig. 329 - Vertical probe holder parts


10.9. Heavy Duty Vertical Probe Holder



BOM ID	Part #	Description
1	EA154	Probe Holder Arm Adjustment Knob
2	PHS049	Heavy Duty Probe Holder Subassembly
3	PH0165	Heavy Duty Probe Holder Arm, Standard, Drop
4	MD074-020	BHCS, M5 x 0.8 x 20 mm, SST
5	<i>See Heavy Duty Yoke Style</i>	
6	PH0011-X	Pivot Button Style (<i>See Pivot Button Style</i>)

Fig. 330 - Heavy duty vertical probe holder parts


10.10. Corrosion Thickness Probe Holder



BOM ID	Part #	Description
1	BG0091	Cable Clip
2	<i>See Probe Holder Receptacle and Wear Plate</i>	
3	MD049-012	SHCS, M3x0.5 x 12 mm, SST
4	MD049-020	SHCS, M3x0.5 x 20 mm, SST
5	EA599	2.5 mm (0.098 in) Hex Driver
6	MA264	SHSS, M8 x 1.25 x 12 mm, dog point, SST

Fig. 331 - Corrosion thickness probe holder parts


10.11. Encoded Skew Vertical Probe Holder



BOM ID	Part #	Description
1	BG0091	Cable Clip
2	PH0082	Knurled Knob, M4 x 0.7 x 10 mm, SST, 3 mm stand off, SST
3	PH0011-X	<i>see Pivot Button Style</i>
4	PH0237	<i>Arm Style: Nozzle, Extra Short</i>
5	PHS069	Encoded Skew Vertical Probe Holder Subassembly
6	PHS068	Encoded Skew Vertical Probe Holder Slide
7	BTS018	Brake Handle

Fig. 332 - Encoded skew vertical probe holder parts

10.12. 3-Axis Nozzle Scanner Add-On Kit



BOM ID	Description	Description
1	BGS070	Pivot, Tapered Lock
2	CXS111	Extension Bracket
3	BG0038-20	Frame Bar, 20 cm
4	BG0091	Cable Clip
5	BG0090-35	Frame Bar with Ruler, 35 cm
6	CEA029	3-Axis Nozzle Case
7	UMA038-X-07.5	3-Axis Encoder Cable, 7.5 m (see Encoder Connector Type)
8	CEG039	Nozzle Spare Parts Kit
9	CJS017-S-0.6	Slider PPS Encoder
10	CJS008	Slider PPS Slider
11	EA212	Knurled Knob, M4 x 0.7 x 8 mm, SST
12	CJS001	Slider PPS Main Knob
13	MD074-016	BHCS: M5 x 0.8 x 16 mm, SST
14	BT0014	Dovetail Nut
16	see Slider PPS Encoded Leadscrew	

Fig. 333 - 3-axis nozzle scanner add-on kit parts

10.12.1. Slider PPS Encoded Leadscrew









Part #	Length		Part #	Length	
CJS009-16	16 cm (6.3 in)		CJS009-21	21 cm (8.3 in)	
CJS009-23	23 cm (9.1 in)		CJS009-28	28 cm (11 in)	
CJS009-33	33 cm (13 in)		CJS009-38	38 cm (15 in)	
CJS009-43	43 cm (16.9 in)		CJS009-48	48 cm (18.9 in)	

Fig. 334 - Slider PPS encoded leadscrew selection

10.13. Probe Holder Components

10.13.1. Arm Style











Arm Style	Part #		Arm Style	Part #	
A Standard, Flat	PH0090		B Short, Flat	PH0089	
C Long, Flat	PH0099		D Standard, Drop	PH0093	
E Short, Drop	PH0092		F Long, Drop	PH0094	
G Standard, Extra-Drop	PH0096		H Short, Extra-Drop	PH0095	
I Extra-Short, Flat	PH0159		J Extra-Short, Drop	PH0161	

Fig. 335 - Probe holder arm selection

10.13.2. Yoke Style

Yoke Style	Part #	Length		Yoke Style	Part #	Length	
S Standard	PHS052	6.3 cm (2.47 in)		W Wide	PHS063	7.9 cm (3.06 in)	

Fig. 336 - Probe holder yoke selection

10.13.3. Swing Arm Style

Swing Arm Style	Part #	Length		Swing Arm Style	Part #	Length	
Short	PH0069	4.1 cm (1.61 in)		Long	PH0100	4.6 cm (1.81 in)	

Fig. 337 - Swing arm selection

NOTE: Short swing arm only compatible with standard yoke style.

10.13.4. Heavy Duty Yoke Style

Yoke Style	Part #	Length		Yoke Style	Part #	Length	
S Standard	PHS048	8.3 cm (3.26 in)		W Wide	PHS047	12.2 cm (4.79 in)	

Fig. 338 - Heavy duty yoke selection

10.13.5. Pivot Button Style











	Pivot Hole Size	Wedge Type			Pivot Hole Size	Wedge Type		
01	8.0 mm (0.315 in)	Olympus PA			02	5.0 mm (0.197 in)	Olympus TOFD	
03	2.7 mm (0.106 in)	Sonatest DAAH PA			04	9.5 mm (0.375 in)	-	
06	3.0 mm (0.118 in)	-			07	2.3 mm (0.09 in)	-	
08	Conical Head	-			09	5 mm (0.197 in) Internal	Zetec PA/TOFD	
11	3 mm (0.118 in) Internal	-			14	4 mm (0.157 in)	-	

Fig. 339 - Pivot button selection

NOTE: Additional probe holder pivot button types available.
(contact Jireh Industries Ltd. on page 1)

10.14. Probe Holder Receptacle and Wear Plate










Part #	Wear Plate	Receptacle		Part #	Wear Plate	Receptacle	
PHS066-A	Curved	9.53 mm (0.375 in) dia.		PHS066-B	Curved	12.7 mm (0.5 in) dia.	
PHS066-C	Curved	19 mm (0.75 in) dia.		PHS066-E	Curved	25.4 mm (1 in)	
PHS067-A	Flat	9.53 mm (0.375 in) dia.		PHS067-B	Flat	12.7 mm (0.5 in) dia.	
PHS067-C	Flat	19 mm (0.75 in) dia.		PHS067-D	Flat	Technisonic	
PHS067-E	Flat	25.4 mm (1 in)					

Fig. 340 - Probe holder receptacle and wear plate selection

10.15. Variable Components

10.15.1. Frame Bar













Part #	Length		Part #	Length	
BG0038-05	5 cm (1.97 in)		BG0038-10	10 cm (3.94 in)	
BG0038-15	15 cm (5.91 in)		BG0038-20	20 cm (7.87 in)	
BG0038-25	25 cm (9.84 in)		BG0038-30	30 cm (11.81 in)	
BG0038-35	35 cm (13.78 in)		BG0038-40	40 cm (15.75 in)	
BG0038-45	45 cm (17.72 in)		BG0038-50	50 cm (19.69 in)	
BG0038-55	55 cm (21.65 in)				

Fig. 341 - Frame bar selection

10.15.2. Automated Crawler Medium Temperature Add-On Kit



BOM ID	Part #	Description
1	CXG031-04.5	Automated Crawler Medium Temperature Add-On Kit
2	CXS102	Medium Temperature Installation/Removal Mat
3	CX0371-04.5	Medium Temperature Sleeve
4	CXS114	Medium Temperature Clamp
5	CXS112	Medium Temperature Mount

Fig. 342 - Automated Crawler Medium Temperature Add-On Kit

10.16. Accessories

10.16.1. Preamp Bracket

Part #	Description
CES029	Preamp Bracket
CES029-V	Preamp Bracket with Velcro




Fig. 343 - Preamp bracket

10.16.2. NAVIC Backpack

Part #	Description
CXS077	Backpack with Velcro
CXS063	Velcro Strap





Fig. 344 - NAVIC backpack


10.16.3. Battery Powered Optical Guide



BOM ID	Part #	Description
1	BGS068	Perpendicular Dovetail Mount
2	CX0490	Line Laser, Battery Powered, Class 1
3	CXS082	Optical Guide Clamp

Fig. 345 - Battery powered optical guide

10.17. Cases



BOM ID	Part #	Description
1	CXA044	NAVIC Crawler Case
2	CXA023	Umbilical / Probe Holder Frame Case
3	CMA016	Motorized Pump / Umbilical Case
4	EA421	Case

Fig. 346 - Cases

DISPOSAL

WEEE Directive

In accordance with European Directive on Waste Electrical and Electronic Equipment (WEEE), this symbol indicated that the product must not be disposed of as unsorted municipal waste, but should be collected separately. Refer to Jireh Industries for return and/or collection systems available in your country.



LIMITED WARRANTY

WARRANTY COVERAGE

Jireh Industries warranty obligations are limited to the terms set forth below: Jireh Industries Ltd. (“Jireh”) warrants this hardware product against defects in materials and workmanship for a period of THREE (3) YEARS from the original date of purchase. If a defect exists, at its option Jireh will (1) repair the product at no charge, using new or refurbished replacement parts, (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, or (3) refund the purchase price of the product. A replacement product/part assumes the remaining warranty of the original product or ninety (90) days from the date of replacement or repair, whichever provides longer coverage for you. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Jireh’s property. When a refund is given, your product becomes Jireh’s property.

OBTAINING WARRANTY SERVICE

To utilize Jireh’s warranty service you must ship the product, at your expense, to and from Jireh Industries. Before you deliver your product for warranty service you must phone Jireh and obtain an RMA number. This number will be used to process and track your product. Jireh is not responsible for any damage incurred during transit.

EXCLUSIONS AND LIMITATIONS

This Limited Warranty applies only to hardware products manufactured by or for Jireh Industries. This warranty does not apply: (a) to damage caused by accident, abuse, misuse, misapplication, or non-Jireh products; (b) to damage caused by service (including upgrades and expansions) performed by anyone who is not a Jireh Authorized Service Provider; (c) to a product or a part that has been modified without the written permission of Jireh.

Jireh Industries Ltd.
53158 Range Road 224
Ardrossan AB T8E 2K4
Canada

Phone: 780-922-4534

jireh.com

HydroFORM™ is a trademark of Olympus.

Kopr-Kote® is a registered trademark of Jet-Lube, Inc.

Lemo® is a registered trademark.

All brands are trademarks or registered trademarks of their respective owners and third-party entities.

Changes or modifications to this unit or accessories not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

All specifications are subject to change without notice.

© 2021 - 2024 JIREH Industries Ltd.



Jireh Industries Ltd.
53158 Range Road 224
Ardrossan, Alberta
Canada
T8E 2K4

780-922-4534

jireh.com